

**TM 5-3825-223-12 DISTRIBUTOR, WATER, TANK, TYPE 1000 GAL CAPACITY-1970**

# **TM 5-3895-272-12**

**DEPARTMENT OF THE ARMY TECHNICAL MANUAL**

---

RETURN TO GOV. DEPT. CLERK

**OPERATOR AND  
ORGANIZATIONAL MAINTENANCE MANUAL**

**ROLLER, MOTORIZED: GASOLINE ENGINE DRIVEN,  
2 WHEEL, 5 TO 8 TON, W/SPRINKLER  
(HUBER MODEL T58M)  
FSN 3895-842-5326**

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**OCTOBER 1967**



## **SAFETY PRECAUTIONS**

### **BEFORE OPERATION**

- Never refuel the roller near an open flame or with the engine running.
- Always provide a metal-to-metal contact between the container and tank when refueling.
- Never attempt an adjustment of the roller with the engine running.
- Be sure the operator's platform is free of oil, grease, ice or mud.
- Be sure all operator's controls are in neutral position before starting the engine.
- Check that the brakes are in good operating condition before starting operations.
- Do not use a lifting device with a capacity of less than 30,000 pounds when lifting the roller.
- Do not allow the unit to swing while it is suspended. Failure to observe this warning may result in serious injury or death to personnel or damage to the equipment.

### **DURING OPERATION**

- Always stop the engine before making adjustments or repairs on any part of the roller.
- Keep the roller in gear when going down grades. On very steep grades, use the brakes to prevent runaway speeds and damage to the torque converter.
- Never mount or dismount while the roller is in motion.
- Avoid breathing the smoke or vapor which is generated when using the fire extinguisher.
- Do not operate the roller in an inclosed area without proper ventilation for the exhaust.
- Never attempt an adjustment of the roller with the engine running.

### **AFTER OPERATION**

- Always provide a metal-to-metal contact between the container and fuel tank when refueling.
- Always apply the parking brake when leaving the machine on an inclined surface.

Changes in Force: C 1 and C 3

**\*TM 5-3895-272-12**  
**C 3**

Change }  
No. 3 }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
Washington, DC, 10 October 1972

**Operator and Organizational Maintenance Manual**  
**ROLLER, MOTORIZED; GASOLINE ENGINE DRIVEN; 2-WHEEL:**  
**5 to 8 TON; W/SPRINKLER (HUBER MODEL T58M)**  
**FSN 3895-842-5326**

TM 5-3895-272-12, 17 October 1967, is changed as follows:

*Page 1-1.* Paragraph 1-1d is superseded as follows:

*d.* Recommendations for Maintenance Publications Improvements. You can improve this manual by calling attention to errors and by recommending improvements, using DA Form 2028 (Recommended Changes to Publications) or by a letter, and mailing direct to Commander, US

Army Troop Support Command, ATTN: AMSTS-MP, 4300 Goodfellow Boulevard, St. Louis, Missouri 63120. A reply will be furnished direct to you.

*Page 2-1,* paragraph 2-3. Add subparagraph *f* after table 2-2.

*f. Maintenance and Operating Supplies* For Maintenance and Operating supplies see Table 3.

---

\*This change supersedes C 2, 5 June 1972.

Table 3. Maintenance and Operating Supplies

(1) Component application	(2) Federal stock number	(3) Description	(4) Quantity required 1/haltal operation	(5) Quantity required 1/8 hr operation	(6) Notes
0101 CRANKCASE (1)	9150-265-9435 (2) 9150-265-9428 (2) 9150-242-7603 (2)	OIL, LUBRICATING 5 gal pails as follows: OE-30 OE-10 OES	5 qt	(3) (3) (3)	(1) Includes quantity of oil to fill engine oil system as follows:  5 qt—CRANKCASE 1 qt—oil filter
0203 TORQUE CONVERTER		OIL, LUBRICATING: (4) OE-10 OES	7-1/2 qt	(3) (3) (3)	(2) See C9100-1L for additional data and requisitioning procedure
0304 AIR CLEANER		OIL LUBRICATING: (4) OE-30 OE-10 OES	1 qt	(3) (3) (3)	(3) See current LO for grade ap- plication and replenishment intervals.
0306 TANK, FUEL	9130-160-1818 9130-160-1830	FUEL GASOLINE: bulk as follows: Automotive combat 91A Automotive, combat 91C	25.5 (5) 16 qt	40 gal (6)	(4) Use oil as prescribed in item 1
0501 RADIATOR	6850-224-8730	WATER: ANTIFREEZE: 5 gal cans as follows: antifreeze ethylene glycol	11 qt		(5) Tank capacity
0800 TRANSMISSION	6850-174-1806	ANTIFREEZE: 55 gal drums as follows: Antifreeze: compound, artic LUBRICATING OIL GEAR 5 gal cans as follows: GO-90 GOS	16 qt		(6) Average fuel consumption is 5.0 gal per hour of continuous operation.
1103 FINAL DRIVE GEARS	9150-577-5844 9150-257-6440 9150-234-5197 (2) 9150-234-5199 (2)	LUBRICATING, GEAR 5-lb can as follows:  CW-11A CW-11B	9 qt (5)  5 lb 5 lb	(3) (3)	
1413 HYDRAULIC SYSTEM		OIL, LUBRICATING: (4) OE-10 OES	26 qt (5) 130 gal	(3)	
7471 SPRINKLER SUPPLY TANK		WATER			

Table 3. Maintenance and Operating Supplies—Continued

(1) Component application	(2) Federal stock number	(3) Description	(4) Quantity required t/initial operation	(5) Quantity required t/8 hra operation	(6) Notes
GREASE POINTS	9150-190-0905 (2)	GREASE, AUTOMOTIVE AND ARTILLERY: (3) 5-lb. can as follows: GAA	5 lb	1 lb	

Page 3-1. Paragraph 3-1 is superseded as follows:

### 3-1. Special Tools and Equipment

A hydraulic tester (FSN 4910-868-6871) is required to test the hydraulic system pressure.

Page 3-53, paragraph 3-114. Add sub-paragraph e. and f.

#### e. Hydraulic Pressure Test.

(1) Pressure control valve test. Disconnect the hydraulic hose that fruns from hydraulic control valve to steering cylinder (cylinder end) (fig. 3-73) and install a pipe tee.

(2) Install the hydraulic tester at this point.

(3) Start engine then pull steering lever hard over (to either side) and hold or block in this po-

sition after cylinder piston has reached end of stroke, take pressure reading.

(4) If pressure reading is not 500 PSI adjust pressure valve in accordance with fig. 3-71. If 500 psi cannot be obtained test hydraulic pump (see para f below).

(5) Remove hydraulic tester reconnect hose on to cylinder.

#### f. Hydraulic Pump Pressure Test.

(1) Disconnect hydraulic output line at hydraulic pump (fig. 3-70) and install pipe tee.

(2) Install hydraulic tester at his point. Start engine and check pressure, it should be 500 to 800 PSI if the pump is working.

(3) If the pump pressure is not at least 500 PSI, replace pump.

Page B-1. Appendix B is superseded as follows:

## APPENDIX B BASIC ISSUE ITEMS LIST AND ITEMS TROOP INSTALLED OR AUTHORIZED LIST

### Section I. INTRODUCTION

#### B-1. Scope

This appendix lists items required by the operator for operation of the roller.

#### B-2. General

This list is divided into the following sections:

a. *Basic Issue Items List*—Section II. Not applicable.

b. *Items Troop Installed or Authorized List*—Section III. A list of items in alphabetical sequence, which at the discretion of the unit commander may accompany the roller. These items are NOT SUBJECT TO TURN-IN with the roller when evacuated.

#### B-3. Explanation of Columns

The following provides an explanation of columns in the tabular list of Basic Issue Items List, Section II, and Items Troop Installed or Authorized

ability

ie

Code	Explanation
P	Repair parts, special tools and test equipment supplied from GSA/DSA or Army supply system and authorized for use at indicated maintenance levels.
P2	Repair parts, special tools and test equipment which are procured and stocked for insurance purposes because the combat or military essentiality of the end item dictates that a minimum quantity be available in the supply system
(2)	Maintenance code, indicates the lowest level of maintenance authorized to install the listed item. The maintenance level codes is—

Code	Explanation
C	Crew/Operator

(3) Recoverability code, indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are non-recoverable. Recoverability codes are:

Code	Explanation
R	Applied to repair parts (assemblies and components) special tools and test equipment which are considered economically reparable at direct and general support maintenance levels.
S	Repair parts, special tools, test equipment and assemblies which are economically reparable at DSU and GSU activities and which normally are furnished by supply on an exchange basis.

b. *Federal Stock Number*. This column indicates the Federal stock number assigned to the

item and will be used for requisitioning purposes.

c. *Description*. This column indicates the Federal item name and any additional description of the item required.

d. *Unit of Measure (U/M)*. A 2-character alphabetic abbreviation indicating the amount or quantity of the item upon which the allowances

are based, e.g., ft, ea, pr, etc.

e. *Quantity Furnished With Equipment (BIIL)*. (Not applicable).

f. *Quantity Authorized (Items Troop Installed or Authorized)*. This column indicates the quantity of the item authorized to be used with the equipment.

### Section III. ITEMS TROOP INSTALLED OR AUTHORIZED LIST

(1) Smr code	(2) Federal stock number	(3) Description  Usable on code	(4) Unit of meas	(5) Qty auth
	7520-559-9618 4910-868-6871	CASE, MAINTENANCE AND OPERATION MANUALS TESTER, Hydraulic circuit, portable carrying case type 7x8-3/4x11, flow gage scale range 4.25 GPM 12-15 GPM temperature range 0.250 degree pressure gage 0-8000 PSI (FMC 08832) number PT100E.	EA EA	1 )

Page C-5. Group 1410 Pump and Pump Drive line  
2 column 3B add "0"

Page C-6. Group 1414 Steering Systems Valves,  
Line 2 column 3B add "0"

Page C-7. Section III, column 2 add "0"; Column

3 is changed to read "Tester, hydraulic"; column  
4 add "4910-868-6871."

Section IV, column 1 add "F-B"; column 2 add  
"Test hydraulic control valve and hydraulic  
pump pressure."

By Order of the Secretary of the Army:

Official:

VERNE L. BOWERS

Major General, United States Army  
The Adjutant General

CREIGHTON W. ABRAMS  
General, United States Army  
Chief of Staff

Distribution:

To be distributed in accordance with DA Form 12-25B (qty rqr block No. 433) Operator's Maintenance requirements for Pavers, Bituminous.



CHANGE }  
No. 1 }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D. C., 24 June 1968

### Operator and Organizational Maintenance Manual

## ROLLER, MOTORIZED: GASOLINE ENGINE DRIVEN, 2 WHEEL, 5 TO 8 TON, W/SPRINKLER (HUBER MODEL T58M)

FSN 3895-842-5326

TM 5-3895-272-12, 17 October 1967, is changed as follows:

*Page 3-1.* Paragraph 3-3 is superseded as follows:

### 3-3. General Lubrication Information

*a. Care of Lubricants.* Keep all lubricants in sealed containers and store in a clean, dry place away from external heat. Allow no dirt, dust, water, or foreign material of any kind to mix with the lubricants. Keep all lubrication equipment clean and ready for use.

*b. Cleaning.* Keep all external parts not requiring lubrication, clean of lubricants. Before lubricating the equipment, wipe all lubrication points free of dirt and grease. Clean all lubrication points after lubrication of excess grease to prevent the accumulation of dirt or foreign matter.

Paragraph 3-4a and 3-4c are rescinded.

Paragraph 3-4c (1) is superseded as follows:

(1) The points of lubrication will be covered in the current Lubrication Order. Follow the instructions and use the specified lubricants.

*Page 3-3 and 3-4.* Figure 3-1(1) and (2) are rescinded.

*Page 3-10.* Figure 3-6, item 11, paragraph reference "3-87" is changed to read "3-88."

*Page 3-16.* Paragraph 3-23, line 5. "(para 2-7)" is changed to read "(Para 3-10)."

*Page 3-17.* Paragraph 3-26, line 12. "Replace thermostat (para 3-75)" is changed to read "Replace thermostat (para 3-79)."

Paragraph 3-28, line 9. "(para 3-95)" is changed to read "(para 3-96)."

*Page 3-25.* Paragraph 3-63b(2) is superseded as follows:

(2) Replace a damaged or defective regulator as necessary.

*Page 3-26.* Paragraph 364b(2) is superseded as follows:

(2) Replace a worn, defective or damaged starter as necessary.

Paragraph 3-65a is superseded as follows:

#### *a. Removal.*

(1) Remove carburetor (para 3-55).

*Note.* The magneto can be removed without removing the carburetor but to do so necessitates partial disassembly of the magneto. To remove the magneto as a complete assembly, the carburetor must be removed.


(2) Refer to figure 3-31 and remove the magneto.

*Page 3-27.* Paragraph 3-65f is superseded as follows:

#### *f. Installation and Timing.*



(1) Refer to figure 3-33.1 and time the magneto.



STEP 1. REMOVE THE REAR SPARK PLUG (NO. 6). PLACE THUMB OVER THE SPARK PLUG HOLE AND CRANK ENGINE BY HAND UNTIL AIR IS EXHAUSTING.

STEP 2. SET PISTON ON TOP DEAD CENTER BY SLOWLY CRANKING UNTIL THE DC MARK ON FLYWHEEL WILL LINE UP WITH THE POINTER ON THE FLYWHEEL HOUSING.

STEP 3. WITH MAGNETO REMOVED FROM ENGINE, PUT IT FIRMLY IN A VICE, LINED WITH SOFT CLOTH, AND TURN DRIVE GEAR UNTIL LEAD TO NO. 6 PLUG FIRES.

NOTE: NO. 6 PLUG LEAD IS AT 5 O'CLOCK POSITION WHEN FACING DISTRIBUTOR END.

STEP 4. TURN MAGNETO DRIVE GEAR COUNTERCLOCKWISE ABOUT 1/4 TURN SO AS TO MESH WITH THE CAMSHAFT GEAR.

STEP 5. CHECK FRONT END CAMSHAFT GEAR AND MAKE CERTAIN THAT PUNCH-MARKED TOOTH OF CAMSHAFT GEAR IS MESHING BETWEEN THE TWO PUNCH-MARKED TEETH OF THE MAGNETO DRIVE GEAR. (SEE FIG. 3-33)

STEP 6. POSITION MAGNETO ON ENGINE AND TIGHTEN MOUNTING BOLTS SLIGHTLY. CONNECT THE WIRES TO SPARK PLUGS.

STEP 7. START ENGINE AND IDLE AT 600 RPM. USE A TIMING LIGHT CONNECTED TO THE REAR PLUG AND BATTERY SOURCE AND CHECK TO SEE IF TIMING IS DIRECTLY AT "IGN-M" INDICATED BY POINTER. IF NOT, ROTATE MAGNETO UNTIL TIMING IS CORRECT. TIGHTEN MOUNTING BOLTS.

ME 3895-272-12 '3-33.1 C


*Figure 3-33.1. Timing the magneto*

(2) Refer to figure 3-31 and complete installation of magneto.

(3) Install the carburetor (para 3-55).  
g. *Magneto Gear Removal and Installa-*

*tion.* Refer to figure 3-33.2 and remove and install the magneto gear.

*Note.* Remove the coupling plate washer from under the coupling gear bushing before new gear is installed.



ME 3895-272-12/3-33-2 C1

1. 2. Magneto gear, removal and installation.

Page 3-29. Figure 3-33. The "A" portion of illustration is rescinded.

Page B-3. Section II. Source Codes. Delete all reference numbers in Materiel column. Delete Quantity issued with equipment column in its entirety.

Page C-3. Functional group 0108, column I, "O" is changed to read "F". Functional group 0301, line 2, Column D, "C" is changed to read "O".

Page C-4. Functional group 0504 is rescinded.

Functional group 0505, line 1, column I, "O" is changed to read "F".

Functional group 0602, line 1, column D, "O" is changed to read "F".

Page C-5. Functional group 0703, line 3, column D, "C", is changed to read "O".

Functional group 1202 is added after last line of 1201.

"1202 SERVICE BRAKES" Place "O" in columns D and H and "F" in column I.

Page C-7. Functional group 7603, line 2, add "C" to column A and delete "C" from column C.

By Order of the Secretary of the Army:

Official:

KENNETH G. WICKHAM,  
*Major General, United States Army,*  
*The Adjutant General.*

HAROLD K. JOHNSON,  
*General, United States Army,*  
*Chief of Staff.*

Distribution:

*Active Army, ARNG, USAR:*

To be distributed in accordance with DA Form 12-25 (qty rqr block no. 90) Section I, organizational maintenance requirements for Engines, Gasoline, 10-20 HP M.S.

TECHNICAL MANUAL

No. 5-3895-272-12

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D. C., 17 October 1967

## Operator and Organizational Maintenance Manual

### ROLLER, MOTORIZED: GASOLINE ENGINE DRIVEN, 2 WHEEL, 5 TO 8 TON W/SPRINKLER (HUBER MODEL T58M) FSN 3895-842-5326

	Paragraph	Page
CHAPTER 1. INTRODUCTION		
Section I. General .....	1-1, 1-2	1-1
II. Description and Tabulated data .....	1-3, 1-5	1-1-1-5
CHAPTER 2. OPERATING INSTRUCTIONS		
Section I. Service upon receipt of equipment .....	2-1, 2-4	2-1-2-5
II. Movement to new work site .....	2-5	2-5
III. Controls and instruments .....	2-6, 2-7	2-6
IV. Operation of equipment .....	2-8-2-19	2-16-2-10
V. Operation of auxiliary material used in conjunction with the roller ...	2-20, 2-21	2-11
CHAPTER 3. OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS		
Section I. Operator and organizational maintenance tools and equipment .....	3-1, 3-2	3-1
II. Lubrication .....	3-3, 3-4	3-1
III. Preventive maintenance services .....	3-5-3-7	3-6
IV. Operator's maintenance .....	3-8-3-21	3-11-3-13
V. Troubleshooting .....	3-22-3-46	3-16-3-18
VI. Radio interference suppression .....	3-47-3-51	3-18-3-19
VII. Engine fuel system .....	3-52-3-58	3-19-3-21
VIII. Electrical system .....	3-59-3-70	3-24-3-30
IX. Lubrication system .....	3-71-3-73	3-32-3-33
X. Engine cooling system .....	3-74-3-80	3-35-3-38
XI. Engine .....	3-81-3-87	3-39-3-40
XII. Controls and instruments .....	3-88-3-109	3-44-3-52
XIII. Hydraulic system .....	3-110-3-115	3-52-3-53
XIV. Housing, panels platform, seat assembly, instrument panel and tool box .....	3-116-3-122	3-56-3-57
XV. Rolls and Roll scrapers .....	3-123-3-126	3-60-3-61
XVI. Sprinkler system .....	3-127-3-129	3-62
XVII. Transmission .....	3-130-3-134	3-64
XVIII. Parking brake .....	3-135-3-136	3-64
XIX. Steering yoke and kingpin adjustment .....	3-137	3-65
APPENDIX A. REFERENCES .....		A-1
B. BASIC ISSUE ITEMS LIST, MAINTENANCE AND OPERATING SUPPLIES .....		B-1
C. MAINTENANCE ALLOCATION CHART .....		C-1
INDEX .....		I-1



## CHAPTER 1

### INTRODUCTION

---

#### Section I. GENERAL

##### 1-1. Scope

a. These instructions are published for use by personnel to whom the Huber Model T58M Motorized Roller is issued. They provide information on the operation and organizational maintenance of the equipment. Also included are descriptions of main units and their functions in relationship to other components.

b. Appendix A contains a list of publications applicable to this manual. Appendix B contains the list of basic issue items authorized the operator of this equipment and the list of maintenance and operating supplies required for initial operation. Appendix C contains the maintenance allocation chart.

c. Numbers in parentheses following nomenclature callouts on illustrations indicate quantity; numbers preceding nomenclature callouts indicate preferred maintenance sequence.

d. Report of errors, omissions, and recommendations for improving this publication

by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to DA Publications) and forwarded direct to Commanding General, U.S. Army Mobility Equipment Command, ATTN: AMSME-MPP, 4300 Goodfellow Blvd., St. Louis, Mo. 63120.

e. Report all equipment improvement recommendations as prescribed by TM 38-750.

##### 1-2. Record and Report Forms

a. DA Form 2028 (Depreservation Guide for Vehicles and Equipment).

b. For other record and report forms applicable to operator, crew and organizational maintenance, refer to TM 38-750.

*Note.* Applicable forms, excluding Standard Form 46 (United States Government Motor Vehicles Operator's Identification Card) which is carried by the operator, shall be kept in a canvas bag mounted on equipment.

#### Section II. DESCRIPTION AND TABULATED DATA

##### 1-3. Description

a. *General.* The Huber Model T58M Motorized Roller covered by this manual is classed as a nominal five (5) to eight (8) ton roller for use in compacting materials used in the construction and maintenance of public highways, secondary roads, air fields and other work of similar characteristics.

b. *Engine.* The roller is powered by a Continental gasoline engine Model FS244-6091. The engine is a 244 cubic inch displacement

engine which is governed at a speed of 2,400 rpm (revolutions per minute), no load.

c. *Torque Converter.* The power of the engine is transmitted through a Borg and Beck torque converter directly to the forward and reverse clutches, thus eliminating the conventional master clutch.

d. *Transmission.* The Huber transmission has two speeds forward and two reverse. Power is transmitted from the forward and reverse clutches through the transmission and inter-




Figure 1-1. Roller, motorized, left front, three-quarter view.

mediate gear assembly to the bull gear on the drive roll. Provisions are also made to mount the tailshaft governor and the service brake assemblies on the transmission.

*e. Rolls.* The roller is provided with one drive (compression) roll and a split guide (steering) roll. All rolls are of watertight construction for the introduction of water ballast only. Both rolls are supported by fixed, non-driving axles.

*f. Steering System.* The roller is steered by a completely hydraulic system consisting of a pump, single spool valve, hydraulic cylinder, filter, tank and necessary lines and fittings to complete the system. The system is activated by a single, hand operated control lever.

*g. Sprinkler System.* The sprinkler system is a gravity feed system manually controlled by two (2) foot pedals. The system consists of a water tank, two (2) gate valves, sprinkler tubes and necessary lines and fittings to com-

plete the system. Cocoa mats are provided to evenly distribute the water across the rolls.

*h. Controls.* The roller is provided with dual controls so that it may be operated from either side of the operator's deck.

#### 1-4. Identification and Tabulated data

*a. Identification.* The roller has 2 major identification plates. The information contained on the plates is listed below.

- (1) *U.S. Army data plate.* Located on the right, front side of frame. Gives the make and model, contract number, serial number, Federal stock number, engine serial number, date of warranty, dimensions and weights for the Roller.
- (2) *Transportation data plate.* Located on the right, front side of frame. Gives the weight, overall dimensions, and tie down instructions.




Figure 1-2. Roller, motorized, right rear, three-quarter view.

### b. Tabulated Data.

(1) *Road Roller.*

Manufacturer-----Huber Corporation  
 Model-----T-58-M  
 Type-----Tandem  
 Rolls-----Water ballast type  
 Electrical system--24 v. (volts) dc (direct  
 current)  
 System ground-----Negative

(2) *Engine*

**Manufacturer**.....Continental Motors Corporation  
**Model**.....FS-244-6091  
**Fuel**.....Gasoline  
**Type**.....L-Head  
**Number of cylinders**.....6  
**Bore and stroke**.....3 7/16 x 4 3/4 in. (inches)  
**Displacement**.....244 cu. in. (cubic inches)  
**Compression ratio**.....6.9

Maximum oil pressure-----20—30 psi (pounds per square inch)  
Minimum oil pressure-----7 psi  
Firing order-----1-5-3-6-2-4  
RPM (revolutions per minute) no load. 2,400  
Horse power-----43.8 at 2200 rpm

(3) *Transmission.*

Manufacturer-----Huber Corporation  
 Type-----Sliding gear  
 Speeds  
     Low (frd & rev.)-----0.5 to 3.5  
     High (frd & rev.)-----0.7 to 5.75  
 Lubrication-----Oil bath

(4) *Torque Converter.*

Manufacturer-----Borg & Beck  
Type-----Single stage, 2 phase  
Cooling-----Water



**U. S. ARMY**

ROLLER, MOTORIZED, G.E.D. 2 AXLE, 5 TO 8 TON

MODEL  CONTR. #

SER.  CAPACITY

REG. NO.  GVW  LG

FSN  DATE MFD.  HGT.

ENG. SER.  SHIP WT.  W.

WARRANTY  OR  CUBE

DATE SHIPPED  DATE INSP.  INSP. STAMP

MFD. BY **HUBER CORPORATION**

**A**

**OPERATION INSTRUCTION**

FORWARD AND REVERSE CLUTCH LEVER AT SIDE OF PLATFORM. PUSH LEVER FORWARD TO RUN UNIT FORWARD. PULL LEVER BACK TO RUN UNIT IN REVERSE.

STEERING LEVER AT TOP CENTER OF UNIT. SWING LEVER RIGHT TO TURN RIGHT. LEFT TO TURN LEFT.

TO SET PARKING BRAKE PULL LEVER ON PLATFORM.

CHECK OIL LEVEL IN AIR CLEANER DAILY.

GREASE THROW-OUT COLLAR ON CLUTCHES DAILY. CONSULT OIL CHART FOR LUBRICATION POINTS. (WHEN USING POWER PRESSURE GREASE GUN DO NOT USE OVER 450 AIR PRESSURE.)

CHECK MANUAL FOR TORQUE CONVERTER LUBRICATION. USE GOOD GRADE OF OIL IN ENGINE (SEE LUBRICATION CHART.)

USE CLEAN SOFT WATER IN RADIATOR, REMOVE CAP WHEN DRAINING SYSTEM.

OPERATING WEIGHT		
WITHOUT BALLAST		WITH BALLAST
<input type="text"/>	ON DRIVE ROLL	<input type="text"/>
<input type="text"/>	ON GUIDE ROLL	<input type="text"/>
<input type="text"/>	TOTAL WEIGHT	<input type="text"/>

SERIAL NO.  MODEL

HUBER CORPORATION  
MARION, OHIO-USA

**C**

**TRANSPORTATION DATA FOR  
ROLLER, MOTORIZED, G.E.D.  
2 AXLE, 5 TO 8 TON**

DRIVE ROLL 7611 LBS. GUIDE ROLL 5035 LBS.

WARNING: SHIP WITH GUIDE ROLL BLOCKED AT SIDES ONLY.

EMPLOY LONGITUDINAL AND TRANSVERSE CABLES FOR TIE DOWNS IN BOTH DIRECTIONS.

**B**

MEC 3895-272-12/1-3

Figure 1-3. Identification plates.

(5) *Clutches.*  
 Manufacturer.....Twin Disc Company  
 Number.....CL-210  
 Type.....Double plate

(6) *Accessories.*  
 (a) *Engine Governor.*  
 Manufacturer.....Synchro-Start  
 Type.....Overspeed shutdown  
 Model.....GSM  
 (b) *Magneto.*  
 Manufacturer.....Fairbanks Morse  
 Type.....FME 6B-16W  
 (c) *Generator.*  
 Manufacturer.....Electric Autolite Company  
 Model.....GKG 4801 ST  
 Voltage.....24 Volts  
 Amperage rating.....40 A (Amperes)  
 (d) *Generator Regulator.*  
 Manufacturer.....Electric Autolite Company  
 Model.....VBU-4001UT  
 Voltage rating.....24 V  
 Current rating.....40 A  
 Ground.....Negative

(e) *Starter Motor.*  
 Manufacturer.....Delco Remy Division  
 Model.....1108272  
 Voltage rating.....24 V  
 (f) *Carburetor.*  
 Manufacturer.....Zenith, Carburetor Division  
 Model.....63AW10  
 (g) *Air Cleaner.*  
 Manufacturer.....Donaldson Company, Inc.  
 Model.....FGA 06-0017  
 (h) *Oil Filter.*  
 Manufacturer.....Fram  
 Type.....Replaceable element  
 Model.....F21P  
 Element number.....C21P  
 (i) *Hydraulic Pump.*  
 Manufacturer.....Hydrex Division  
 Model.....1515C14A3DR  
 (j) *Tailshaft Governor.*  
 Manufacturer.....Pierce Governor Company, Inc.  
 Model.....GC-860

*(k) Hydraulic Oil Filter.*

Manufacturer.....Gresen  
 Model.....FA-103  
 Element.....1553

*(7) Capacities.*

Engine cooling system.....4 gallons  
 Fuel tank.....25.5 gallons  
 Hydraulic system.....26 quarts  
 Sprinkler tank.....130 gallons  
 Engine crankcase.....5 quarts  
 Lubrication system, 6 quarts  
 W/filter.

Transmission case.....9 quarts  
 Torque converter.....7 1/2 quarts  
 Air cleaner cup.....1 quart

*(8) Nut and Bolt Torque Data.*

Different sizes and grades of studs, capscrews and nuts are used on the Continental engine. The following table (1-1) should be consulted when tightening such fasteners. The values given are in foot-pounds.

Table 1-1. Nut and Bolt Torque Data

Size diameter	5/16"	3/8"	7/16"	1/2"	9/16"	5/8"
Cylinder heads	-----	35-40	70-75	100-110	130-140	145-155
Main brgs. and conn. rods	20-25	35-40	70-75	85-95	100-110	-----
Flywheels	20-25	35-40	70-75	85-95	100-110	145-155
Manifolds	15-20	25-30	50-55	80-90	100-110	130-140
Gear covers, water pumps, front and rear ends, oil pans	15-20	25-30	50-55	80-90	-----	-----
Flywheel hsgs.	15-20	25-30	50-55	80-90	115-125	-----
Camshaft nut cast iron camshaft steel camshaft	65-70 120-130					
Spark plugs				35		

*(9) Adjustment Data.*

Fanbelt deflection.....1/2 inch  
 Hydraulic pump drive 1/2 inch  
 belt deflection.  
 Intake valves (cold)......014 inch  
 Exhaust valves (cold)......014 inch  
 Distributor contact gap......020 inch  
 Spark plug gap:  
 Std. Plug......025 inch  
 Resistor Plug......035 inch

*Timing:*

Normal, set pointer at...."DC" or "IGN M"  
 At high altitudes, or  
 low altitudes with  
 premium gas, set to.....4° BTC (Before top  
 center) maximum

Hydraulic system pressure...500 psi.

*(10) Dimensions and Weight.*

Wheel base.....121 inches  
 Overall length.....177 inches  
 Overall width.....60 inches  
 Overall height.....7 feet, 3/4 inch  
 Ground clearance.....14 inches  
 Rolling width.....50 inches  
 Weight, net.....12,260 pounds  
 Shipping cubage.....582 cubic feet  
 Shipping weight.....12,680 pounds

*1-5. Differences in Models*

This manual covers only the Tandem Road Roller, Model T58M. No differences exist within the serial number range covered in this manual.




Figure 1-4. Wiring Diagram

## CHAPTER 2

### OPERATING INSTRUCTIONS

---

#### Section I. SERVICE UPON RECEIPT OF EQUIPMENT

##### 2-1. Unloading the Equipment

a. If the roller is to be removed from the flat car by a crane, attach the sling to the lifting eyes and remove from the car. Refer to Figure 2-1 for lifting points.

**Warning:** Do not use a lifting device with a capacity of less than 20,000 pounds. Do not allow the unit to swing while it is suspended. Failure to observe this warning may result in serious injury or death to personnel or damage to the equipment.

b. If the roller is to be driven off the flat car under its own power, the engine must be deprocessed and the batteries connected and activated (para 2-2 and 2-3).

c. Remove the two blocks from the drive roll which oppose the movement of the roller. Refer to figure 2-1 for blocking and tiedown points.

d. Construct a suitable ramp, if necessary. Release the parking brake (para 2-7) and slowly drive the roller off the car. Refer to fig. 2-1.

**Caution:** The guide roll will not respond to the steering lever if the engine is not running.

##### 2-2. Unpacking Equipment

a. Remove banding and crates from the roller.

b. Open boxes carefully and remove the spare parts, fire extinguisher, cocoa mats, water hose (for sprinkler system), seat cushion, plug wrench.

c. Battery electrolyte is packed separately, and should be carefully unpacked.

**Warning:** Use care in handling the containers of electrolyte as severe burns will result if acid is spilled on the skin.

d. Remove the tape from the tool box and remove the overpack kit, ignition key, publications and control lever rubber grips from the tool box.

e. Remove the tape covering the instruments on the instrument panel.


f. Remove the tape covering electrical sockets and engine openings.

g. Remove the tape from the battery terminals and battery filler caps. Remove the battery cables that are taped to the carrier and remove the preservative from the cable connectors.


##### 2-3. Inspecting and Servicing Equipment

a. Perform the following inspection and services upon receipt of equipment.

- (1) Check all parts against the packing list for loss, theft, or damage.
- (2) Inspect the roller for damage that may have occurred during shipping or unloading. Check for bent panels, damaged instruments and controls.
- (3) Remove side covers and check the engine for evidence of leaks, damaged or disconnected lines and wires, or other defects.
- (4) Check the carburetor and governor linkage for damage and/or evidence of tampering.
- (5) Check the radiator hose and fan belt for condition and adjustment (figure 3-11 for belt adjustment.)



A. BLOCKING AND TIE-DOWN POINTS.



B. UNLOADING RAMP.

MEC 3895-272-12/2-1

Figure 2-1. Blocking, tiedown and lifting points and unloading ramp.

- j) Locate the envelope, attached near the controls, containing the depreservation guide, DA Form 2258 (Depreservation Guide for Vehicles and Equipment). Perform the depreservation services described therein to prepare the roller for operation.
- k) Remove the battery caps and pour into each cell sufficient electrolyte to cover the plates to a depth of 3/8 inch. Install battery caps.

**Warning:** Use care in handling the containers of electrolyte as severe burns will result if acid is spilled on skin.

- l) Connect the battery cables to the batteries by reversing the instructions on figure 3-26.
- m) Clean around the filler caps on the tanks before servicing to prevent entry of any foreign matter into tanks.
- n) Fill the radiator with fresh water, using water as free of minerals as possible. Use an antifreeze mixture if below-freezing temperatures are expected.

*Note.* Consult antifreeze table 2-2 to prepare coolant solution.

- (11) Fill fuel tank and perform lubrication service as instructed in paragraph 3-4.

*Note.* When adding fuel to tank before initial operation, fill tank completely full of gasoline to dilute the preservative in the tank to prevent clogging of the lines.

b. Perform Daily Preventative Maintenance Services. Refer to illustrated tabulated listing figure 3-5, in Maintenance Instructions.

c. Inspect machine for physical damage or missing parts as follows:


- (1) Check for dented panels and rolls, bent control levers, broken glass in floodlights or instruments in control panel that may have occurred during shipping and/or unloading.
- (2) Check sprinkler system for any missing caps, plugs, or fittings. Make sure that all hoses are securely in place, and in serviceable condition.
- (3) Inspect steering, brake, and transmission linkage for bent or broken rods, tie rod ends, or clevises.

d. Test batteries with a hydrometer to determine if they are fully charged. Refer to Specific Gravity table 2-1.


*Note.* Consult TM9-6140-200-15 for servicing and testing batteries used in this roller.

Table 2-1. Specific Gravity Readings Corrected for Temperature

Specific gravity	Specific gravity at acid temperatures.					
	-65°F.	-40°F.	-20°F.	-10°F.	0°F.	20°F.
1.338	1.338	1.328	1.320	1.316	1.312	1.304
1.327	1.327	1.317	1.309	1.305	1.301	1.294
1.317	1.317	1.307	1.299	1.295	1.291	1.283
1.307	1.307	1.297	1.289	1.285	1.281	1.273
1.297	1.297	1.287	1.279	1.275	1.271	1.263
1.287	1.287	1.277	1.269	1.265	1.261	1.253
1.277	1.277	1.267	1.259	1.255	1.251	1.243
1.247	1.247	1.237	1.229	1.225	1.221	1.213
Specific gravity	Specific gravity at acid temperatures.					
	40°F.	80°F.	100°F.	110°F.	120°F.	
1.296	1.296	1.280	1.272	1.268	1.265	
1.286	1.286	1.270	1.262	1.258	1.255	
1.276	1.276	1.260	1.252	1.248	1.245	
1.266	1.266	1.250	1.243	1.239	1.235	
1.256	1.256	1.240	1.233	1.229	1.225	
1.246	1.246	1.230	1.223	1.219	1.215	
1.236	1.236	1.220	1.213	1.209	1.205	
1.206	1.206	1.190	1.182	1.178	1.174	



A. RIGHT SIDE VIEW.



B. LEFT SIDE VIEW.

MEC 3895-272-12/2-2

Figure 2-2. Inspection points.

e. Prepare equipment for cold weather operation, if to be used in area where temperature level makes this necessary. Refer to table

2-2, Freezing Points, Composition, and Specific Gravities of Military Antifreeze Materials.

Table 2-2. Freezing Points, Composition, and Specific Gravities of Military Antifreeze Materials.

Lowest expected ambient temp 0°F.	Pints of inhibited glycol per gal of coolant <sup>1</sup>	Compound Antifreeze arctic <sup>2</sup>	Ethylene glycol coolant solution specific gravity at 68°F. <sup>3</sup>
+20-----	1 1/2	Issued full strength and ready mixed for 0° to -65° F. temperatures for both initial installation and replenishment of losses.  DO NOT DILUTE WITH WATER OR ANY OTHER SUBSTANCE	1.022
+10-----	2		1.036
0-----	2 3/4		1.047
-10-----	3 1/4		1.055
-20-----	3 1/2		1.062
-30-----	4		1.067
-40-----	4 1/4		1.073
-50-----	Arctic antifreeze preferred		
-60-----			
-75-----			

<sup>1</sup>Maximum protection is obtained at 60 percent by volume, that is 4.8 pints of ethylene glycol per gallon of solution.

<sup>2</sup>Military Specifications MIL-C-11755 Arctic type, nonvolatile compound is intended for use in the cooling system of liquid-cooled internal combustion engines for protection against freezing primarily in Arctic regions where the ambient temperature remains for extended periods of time close to -40°F. or drops below, to as low as -90°F.

<sup>3</sup>Use an accurate hydrometer. To test hydrometer, use 1 part ethylene glycol type antifreeze to 2 parts water. This should produce a hydrometer reading of 0°F.

Note. Fasten a tag near the radiator filler cap indicating the type of antifreeze.

## 2-4. Installation of Components Which are Packed in Separate Cartons

a. The electrolyte for the batteries is packed separately, and must be poured into the batteries. Refer to paragraph 2-3d and table 2-1.

b. Install fire extinguisher in bracket on control panel. Care should be taken safety pin is not removed or damaged when handling extinguisher.

c. Install cocoa mats on rolls. (para 3-19)

d. Install seat cushion onto seat frame (para 3-117).

e. Install sprinkler hoses for steering roll (para 3-129).

f. Install rifle case on roll hood between park brake and fuel filler.

g. Handle grips must be installed on clutch lever, gearshift lever, steering control lever and throttle control lever. These with the ignition key are packed in the tool box (para 2-2).

## Section II. MOVEMENT TO NEW WORK SITE

### 2-5. Preparation for Movement

a. *Short Move.* The roller can be moved to a new site under its own power. No special preparation is needed.

b. *Long Distance.*

(1) The roller can be transported by a low bed semi-trailer or by railway flat car.

(2) The brakes should be set on the roller, and chocks should be placed behind the rolls to prevent rolling if brakes should not hold. Refer to figure 2-1.

Note. Be sure to drain water from sprinkling system and tank, if transporting in cold weather. Make certain that engine cooling system contains sufficient anti-freeze.



### Section III. CONTROLS AND INSTRUMENTS

#### 2-6. General

This section describes, locates, illustrates, and furnishes operator, crew, or organizational maintenance personnel sufficient information about various controls and instruments for proper operation of the tandem roller.

#### 2-7. Controls and Instruments

The purpose of controls and instruments and their normal and maximum reading are illustrated in figure 2-3 and 2-4.

### Section IV. OPERATION OF EQUIPMENT

#### 2-8. General

a. Instructions in this section are published for information and guidance of personnel responsible for operation of the tandem road roller.

b. The operator must know how to perform any operation of which the road roller is capable. This section gives instructions on starting and stopping the roller, basic operational functions to perform specific tasks for which the equipment is designed. Since nearly every job presents a different problem, the operator may have to vary given procedures to fit the individual job.

#### 2-9. Starting the Engine

##### a. Preparation for Starting.

- (1) Perform the Daily Preventative Maintenance Services.
- (2) Carry out Inspection and Servicing procedures as outlined in Section I, paragraph 2-3a.

b. *Starting the Engine.* See figure 2-3 and start the engine, following sequential steps 1-9.

#### 2-10. Stopping the Engine

a. *Preparation for Stopping.* Allow a hot engine to idle for a few minutes to permit even cooling of engine parts.

##### b. Stopping the Engine.

- (1) Move the throttle lever (fig. 2-4) full forward.
- (2) Turn ignition switch (fig. 2-3) to OFF position.

#### 2-11. Operation under Normal Conditions

##### a. Preparation for Operating Roller.



- (1) Perform the Daily Preventive Maintenance Services, including filling the water tank for sprinkler (para 3-6).
- (2) Start the engine (para 2-9 and fig. 2-3).

b. *Operating the Roller.* See figure 2-4 for details.

##### c. Steering.

- (1) Move the steering control lever to the left to steer left or to the right to steer right. When the guide roll has turned to the desired angle, return the steering control lever to center position. Otherwise, the guide roll will continue to increase steering angle as long as the lever is held off-center.
- (2) When it is desired to straighten the course of motion, move the steering control lever to the opposite side to return the guide roll to straight-ahead position, then release the lever.
- (3) Practice will be necessary to achieve satisfactory control of steering.
- (4) Turn the variable speed steering valve counterclockwise to slow or clockwise to increase speed of steering action. Different steering action will be necessitated depending upon the type of material being rolled.

d. *Turning on Loose Gravel.* Drive at slow speeds when turning on loose gravel to prevent displacing the material and possibly damaging the rolls. Do not make sharp, quick turns.




- A
- STEP 1. ENGAGE PARKING BRAKE.
  - STEP 2. CHECK THAT FORWARD & REVERSE LEVER IS IN "DISENGAGED" POSITION (MIDWAY).
  - STEP 3. PULL THROTTLE LEVER BACK ABOUT 1/3 OF ITS TRAVEL, TO OPEN THROTTLE.
  - STEP 4. PULL CHOK E CONTROL OUT ABOUT 1/3 OF ITS TRAVEL, FARTHER IN COLD WEATHER.
  - STEP 5. TURN IGNITION KEY TO "START" POSITION. AS SOON AS ENGINE STARTS, RELEASE KEY.  
CAUTION: DO NOT OPERATE STARTER MOTOR FOR MORE THAN 30 SECONDS WITHOUT LETTING STARTER COOL FOR 2-3 MINUTES BETWEEN STARTING ATTEMPTS.
  - STEP 6. WHEN ENGINE STARTS, GRADUALLY PUSH CHOK E CONTROL IN AS FAST AS SMOOTH ENGINE FUNCTIONING WILL PERMIT.
  - STEP 7. OBSERVE ENGINE OIL PRESSURE GAGE.  
CAUTION: IF 20-30 PSI DOES NOT REGISTER ON GAGE WITHIN 8-10 SECONDS, TURN SWITCH TO "OFF" POSITION AND INVESTIGATE REASON FOR TROUBLE.
  - STEP 8. LET ENGINE OPERATE AT IDLING RPM FOR A FEW MINUTES, THEN INCREASE RPM TO APPROXIMATELY HALF THROTTLE UNTIL WATER TEMPERATURE GAGE SHOWS READING OF 100° F.  
CAUTION: DO NOT RUN ENGINE FOR LONG PERIODS OF TIME WITHOUT MOVING THE ROLLER. OIL STARVATION IN THE TRANSMISSION WILL DAMAGE PARTS.
  - STEP 9. OBSERVE BATTERY-GENERATOR INDICATOR FOR A READING IN THE GREEN RANGE AT IDLING RPM. IF THE READING IS OTHERWISE, IT IS AN INDICATION OF TROUBLE IN THE ELECTRICAL SYSTEM.

B

MEC 3895-272-12/2-3

Figure 2-3. Starting the Engine



- STEP 1. START ENGINE AND ALLOW IT TO REACH OPERATING TEMPERATURE.
- STEP 2. MAKING SURE THE FORWARD AND REVERSE CLUTCH LEVER IS IN NEUTRAL POSITION, MOVE THE GEARSHIFT LEVER FORWARD TO HIGH OR REARWARD TO LOW RANGE AND RELEASE PARKING BRAKE.
- STEP 3. PULL BACK THROTTLE CONTROL LEVER TO INCREASE ENGINE SPEED. MOVE THE FORWARD AND REVERSE CLUTCH LEVER FORWARD. BE SURE TO MOVE THE LEVER ALL THE WAY FORWARD UNTIL A DEFINITE OVER-CENTER ENGAGEMENT IS FELT. CAUTION: DO NOT SLIP CLUTCHES BY PARTIAL ENGAGEMENT.
- STEP 4. REVERSE THE ROLLER BY MOVING THE FORWARD AND REVERSE CLUTCH LEVER TO THE REAR, FULLY ENGAGING THE CLUTCH.  
NOTE: ROLLER MOTIONS CAN BE SAFELY REVERSED AT SLOW OR MODERATE SPEEDS WITHOUT SLOWING DOWN BY MOVING THE REVERSE CLUTCH LEVER DIRECTLY TO THE OPPOSITE POSITION. HOWEVER, THIS PRACTICE CANNOT BE FOLLOWED WHEN ROLLING FINISHED SURFACES.
- STEP 5. STOP THE ROLLER BY MOVING THE FORWARD AND REVERSE CLUTCH LEVER TO NEUTRAL POSITION, DEPRESSING THE BRAKE PEDAL AS NEEDED AND MOVING THE THROTTLE CONTROL LEVER FORWARD TO IDLE THE ENGINE.
- STEP 6. TO SHIFT GEARS, BRING THE ROLLER TO A COMPLETE STOP. WITH THE FORWARD AND REVERSE CLUTCH LEVER IN NEUTRAL POSITION, MOVE THE GEARSHIFT LEVER TO THE DESIRED RANGE.  
CAUTION: DO NOT ATTEMPT TO SHIFT GEARS WITH THE FORWARD AND REVERSE CLUTCH LEVER ENGAGED OR THE ROLLER IN MOTION.
- STEP 7. STEER ROLLER OVER DESIRED COURSE. REF. PAR. 2-11 c.

MEC 3895-272-12/2-4

Figure 2-4. Operating the Roller.

*e. Turning on Pliable Material.*

- (1) If at all possible, do not turn roller on pliable finish material. Make maneuvers off the end of the strip. If turns must be made, make turns while driving forward rather than backward. This will prevent digging in of the guide roll, particularly of the leading edge of roll, in regard to direction of travel.
- (2) Use a slow turning speed by adjusting the variable speed steering valve.
- (3) Avoid sudden stops or starts while operating on pliable surfaces. Refer to paragraphs 2-12, 2-13.

*f. Using Sprinkler.*

- (1) Use the sprinkler only on bituminous surfaces to prevent asphalt from clinging to the rolls and damaging the surfaces being rolled.
- (2) Depress the right sprinkler control pedal to wet the drive roll, and the left pedal to wet the guide roll.

## 2-12. Operating on Bituminous-Macadam Pavements

*a. Foundation Course.* After the foundation course is evenly laid on the subgrade, roll the course beginning from the sides and gradually work toward the center. Move the roller parallel to the centerline of the road. When rolling a banked curve, roll from the inner to the outer or high edge. The passes should overlap the previous path by about one foot (12 inches) to avoid a ridge.

*b. Wearing Course.* This course will be rolled in the same manner as for the foundation course. Roll the course until no improvement is seen from further operation. Rolling speeds should be between 1 1/2 to 3 miles per hour.

*c. Key or Filler Stone.* When the key or filler stone has been evenly spread over the bitumen, roll the stone as above until a tight, compact surface is obtained.

*d. Cover Stone.* Roll the cover stone in the same manner as the key or filler stone.

### 2-13. Operating on Bituminous-Concrete and Sheet-Asphalt Pavements

*a. General.* In general, rolling of surfaces should be continued until no further improvement is noted in succeeding passes. This will be done in less time than when rolling macadam pavements because the bituminous concrete and sheet-asphalt materials set up quicker. Rolling speeds will be slow, generally between one and one-half and three miles per hour. During the rolling operation, the surfaces must be tested for density and trueness and corrections made at once.

*b. Binder Course.* After the binder course has been evenly distributed and is of uniform density, begin the rolling operation while the course is still hot. Start at the sides and proceed toward the center, overlapping each pass about one foot to avoid a ridge. After this first pattern is finished, roll the surface diagonally in two directions. Use the sprinklers during this operation to prevent asphalt from sticking to the rolls.

*c. Wearing Course.* Roll the wearing course in the same manner described for the binder course.

### 2-14. Handling on Paving Jobs

General rules applicable to all rolling operation are as follows:

*a.* On soft, pliable materials roll at a slow rolling speed, generally between one and one-half to three miles per hour.

*b.* When starting, stopping, and reversing directions of travel on asphaltic surfaces, avoid sudden changes in speed. Otherwise, material will be shoved out of place or marred. Do not stop or change direction in the same spot each time.

*c.* Make turns at the ends of the runs whenever possible to avoid marring the rolled surface. (Refer to para 2-11.)

*d.* Do not leave the roller standing on new or setting pavement surfaces. Depressions will form in the pavement due to weight of the roller.

*e.* Do not use the sprinkling system when rolling subgrades as dirt and fine gravel will adhere to the rolls, spoiling the surface. If

water is to be used for compaction, a sprinkler wagon should be used in advance with time allowed for the surface to dry a bit before rolling.

*f.* Keep the scrapers adjusted and cleaned out. An excess of material behind the scrapers can fall and mar the surface. Trapped, hard stone can hasten wear of scrapers and rolls and very hard stone can groove rolls.

*g.* Extra skill and care are needed when the pavement has obstructions, such as manholes. Care should be taken when approaching an obstruction that the clutch be disengaged in time to prevent the rolls from striking or climbing over the obstruction. Straight passes should be made first as normal as possible, followed by curved passes later.

*h.* Do not allow the roller to drop oil or grease as this will affect asphaltic material, retarding or preventing setting.

### 2-15. Operation in Extreme Cold

*a. General.* Low temperatures require special care and additional maintenance to prevent damage to equipment and to insure unfailing operation.

*b. Lubrication.* Be sure winter grades of lubricants are used. Allow longer time for warming up the engine to insure adequate lubrication reaching vital working parts. Engage clutch slowly when first moving the roller to prevent shock to gears and shafts due to the stiffness of the heavy transmission lubricant.

*c. Fuel System.* Keep the fuel tank filled as much of the time as possible, and always fill the tank at the end of the working day to prevent moisture condensing in the tank. Remove any water that appears in the fuel sediment bowl. Use care when handling fuel to prevent entrance of ice and snow.

*d. Water Supply.* Drain the sprinkler tank as soon as the day's work is over to prevent freeze up. Do not fill sprinkler tank at the start of a day's work until the engine has been started and some heat reaches the tank. Be sure the radiator is adequately protected with antifreeze.



*e. Electrical System.* The insulation on wiring becomes stiff in subzero weather. Move wiring as little as possible to avoid damage. Never add water to batteries unless the engine is to be run for several hours immediately afterward. The water unmixed with electrolyte may freeze and break battery cases.

*f. Drive and Guide Rolls.* The Huber T58M Roller was furnished as a fixed weight roller. However, in the event ballast is added to the rolls, water should be drained from the rolls when freezing temperatures are expected. If for some reason ballast is used when freezing temperatures prevail, fuel oil, kerosene, or other liquids with very low freezing points can be used in place of water.

## 2-16. Operation in Extreme Heat

*a. General.* Extra care must be taken when operating in extreme heat conditions to prevent overheating of equipment.

*b. Lubrication.* Be sure to use the proper grade of lubricants for high temperatures. Check the engine crankcase oil level more frequently and keep level to full mark on dipstick.

*c. Cooling System.* Check the coolant level more frequently. Remove any accumulation of trash from the radiator, and keep the fins cleaned out by using compressed air or water from a hose. Inspect and adjust the fan belt more frequently.

*d. Electrical System.* Check the batteries more frequently for loss of water due to evaporation. Excessive loss of water may indicate too high a charging rate caused by a defective generator regulator.

## 2-17. Dusty or Sandy Areas

*a. General.* Dust and sand penetrate vital parts unless special care is taken to prevent it. Equipment wears out more quickly in dusty, sandy areas than under any other environmental condition.

*b. Lubrication.* Wipe off lubrication fittings before applying grease gun. Wipe off lubricant after servicing. Lubricate sparingly but more often. Clean around filler openings before removing caps or covers for lubrication.

After removal from sandy environment, the gear covers should be removed, the drive gears thoroughly cleaned and relubricated. Service air cleaner, oil filter, and breathers more frequently. Keep lubricants and lubricating equipment covered tightly and clean to keep out abrasive foreign matter. Keep equipment in an inclosure when not in use, or protect from wind by covering with a tarpaulin or the best protection feasible.

*c. Fuel System.* Keep the fuel containers clean and tightly covered. Check fuel sediment bowl more often for deposits of sand and dust.

## 2-18. Salt Water or High Humidity Areas

*a. General.* Salt water causes rapid corrosion. Keep equipment well painted and clean. Wash in clean water frequently, if available. Keep equipment covered to minimize collecting moisture.

*b. Fuel System.* Fill fuel tank at end of day's operation to minimize condensation. Check fuel sediment bowl more often for water.

*c. Electrical System.* Salt water and high humidity cause corrosion and poor connections in electrical components. Use care to prevent damage to the fungus proofing of the electrical components. Remove corrosion from electrical connections when evident.

## 2-19. Operation in High Altitude

*a. General.* As altitude increases, the density of air decreases with resultant decrease in oxygen for combustion and decrease in horsepower.

*b. Fuel System.* Clean and service the air cleaner more often to be sure that the maximum supply of air is available at the intake manifold.

*c. Electrical System.* At higher altitudes there is less tendency for spark knock. The magneto may be advanced to a maximum of 4° over normal setting for some improvement in engine performance (para 3-65).

## Section V. OPERATION OF AUXILIARY MATERIAL USED IN CONJUNCTION WITH THE ROLLER

### 2-20. Fire Extinguisher

*a. Description.* The fire extinguisher is the dry chemical type charged with inert gas under pressure. It is useful for all classes of fires and is safe to use on electrical fires. The chemical is non-toxic to humans and when used on a fire, emits no toxic by-product.

*b. Operation.*

- (1) Open clamp securing fire extinguisher in bracket.
- (2) Remove extinguisher from bracket and pull out safety pin, breaking the wire seal.
- (3) Aim extinguisher nozzle at base of flames and squeeze the grip.
- (4) For general fires or burning liquids, discharge chemical at base of flame with a sweeping motion while advancing.
- (5) For electrical fires, turn off current if possible. Aim stream directly into burning part.

*c. Maintenance.*

- (1) Observe pressure gauge; if hand is in white area, extinguisher is ready for service and needs no further checking. This inspection should be made every 30 days, at least.
- (2) If gauge hand is to the left of white area, pull safety pin, invert extinguisher and squeeze handle until pressure hand is down to zero on gauge. Unscrew valve assembly and remove from cylinder.
- (3) Refill cylinder as necessary with dry chemical powder until complete ex-

tinguisher including valve assembly, weighs amount listed on name plate of cylinder, usually 4 3/4 pounds.

- (4) Remove nozzle from valve assembly, apply air pressure or nitrogen pressure to valve through opening, holding down on handle, to remove any powder remaining in valve.
- (5) Replace valve in cylinder, after placing a small amount of light oil to O ring on threaded area. Tighten hand tight only.
- (6) Use air or nitrogen to charge extinguisher. Attach a suitable moisture trap with proper threaded connection to the valve nozzle seat. Squeeze extinguisher handle and apply air or nitrogen till gauge indicates 150 psi. Release handle and disconnect trap from valve. Reinstall nozzle.
- (7) Insert safety key in handle, seal with wire and lead seal.
- (8) Attach tag stating data and name of person recharging extinguisher.

### 2-21. Trouble Light

*a. Description.* The trouble light is a 25-foot extension light which is stored in the tool box.

*b. Operation.* Remove the cap from the receptacle on the instrument panel. Insert the plug to the bottom, twist clockwise to lock the connection.

*c. Maintenance.* Replace burned out lamp by pushing lamp to bottom of socket, twist and extract the lamp.



## CHAPTER 3

### OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS

---

#### Section I. OPERATOR AND ORGANIZATIONAL MAINTENANCE TOOLS AND EQUIPMENT

##### 3-1. Special Tools and Equipment

No special tools or equipment are required by operator or organizational personnel for maintenance of the tandem road roller.

##### 3-2. Basic Tools and Equipment

Tools and repair parts issued with or authorized for use with the tandem road roller are listed in the Basic Issue Items List.

#### Section II. LUBRICATION

##### 3-3. General Lubrication Information

a. This section contains a reproduction of the lubrication order and lubrication instructions which are supplemental to, and not specifically covered in the lubrication order.

b. The lubrication order shown in figure 3-1 is an exact reproduction of the approved lubrication order for the tandem roller. For the current lubrication order, refer to DA-PAM-310-4 (Military Publications).

##### 3-4. Detailed Lubrication Information

a. *Care of Lubricants.* Store all lubricants in covered containers and keep in protected place. Clean all containers before they are opened to prevent entry of dirt. Clean lubricating equipment before and after use.

b. *Cleaning.* Clean around all lubrication fittings, oil covers, filler caps, and breathers before lubricating. Clean all lubrication points after lubricating to prevent accumulation of foreign matter.

###### c. *Points of Lubrication.*

- (1) The points of lubrication will be covered in the lubrication chart, figure 3-1. Follow the instructions and use the specified lubricants.

- (2) Apply pressure lubricant until clean lubricant oozes from the part being lubricated.

- (3) Do not overfill crankcase or sumps as it is not only wasteful but can be harmful to the equipment.

###### d. *Special Lubrication Instructions.*

- (1) The service intervals are based on hours of normal operation. Shorten intervals to compensate for abnormal operations and severe conditions. During inactive periods, intervals may be lengthened to the point where lubricant protection is assured.

- (2) Drain oil sumps when equipment is hot after operation.

- (3) For information on changing grades of lubricants, refer to Key in lubrication chart.

###### e. *OES Oil.*

- (1) The crankcase oil level must be checked frequently, as oil consumption may increase.

- (2) The oil may require changing more frequently than usual because contamination by dilution and sludge



formation will increase under cold weather operation conditions.

*f. Oil Filter Service.* Service the oil filter as instructed on figure 3-2.

*g. Air Cleaner Service.* Service the air cleaner as instructed on figure 3-3.

*h. Transmission Breather Service.* Service the transmission breather as instructed on figure 3-4.

*i. Torque Converter Sump Breather Service.* Service the torque converter sump breather as instructed on figure 3-4.

# LUBRICATION CHART

## ROLLER, MOTORIZED, 5 TO 8 TON TANDEM, GED (HUBER CORP. MODEL T 58 M)

Reference: TM 5-3895-272-12 and TM 5-3895-272-35

Intervals are based on normal hours of operation. Reduce intervals to compensate for abnormal operations and severe conditions. During inactive periods, sufficient lubrication must be provided for adequate preservation.

Clean fittings before lubricating.


Relubricate after washing or fording.

A dotted circle indicates a drain below.

Clean parts with SOLVENT, dry-cleaning, or with OIL, fuel, diesel. Dry before lubricating.

Lubricate points indicated by dotted arrow shafts on both sides of equipment.

Drain crankcase and gearcases when hot. Fill and check level.



CONTINUED ON  
FOLLOWING PAGE

MEC 3895-272-12/3-1 (1)

Figure 3-1. Lubrication order.






Figure 3-1—Continued.



**Figure 3-2. Oil Filter Service.**



**Figure 3-3. Air cleaner service.**



Figure 3-4. Transmission and Torque Converter Sump breather service.

### Section III. PREVENTIVE MAINTENANCE SERVICES

#### 3-5. General

To insure that the tandem roller is ready for operation at all times, it must be inspected systematically, so that defects may be discovered and corrected before they result in serious damage or failure. The necessary Preventive Maintenance Services to be performed are listed and described in paragraphs 3-6 and 3-7. The item numbers indicate the sequence of minimum inspection requirements. Defects discovered during operation of the unit shall be noted for future correction, to be made as soon as operation has ceased. Stop operation immediately if a deficiency is noted during operation, which would damage the equipment and shortcomings will be recorded together with the corrective action taken on DA Form 2404 (Equipment Inspection and Maintenance Worksheet) at the earliest possible opportunity.

#### 3-6. Daily Preventive Maintenance Services

This paragraph contains an illustrated tabulated listing of Preventive Maintenance Services which must be performed by the operator. The item numbers are listed consecutively and indicate the sequence of minimum requirements. Refer to figure 3-5 for the Daily Preventive Maintenance Services.

#### 3-7. Quarterly Preventive Maintenance Services

a. This paragraph contains an illustrated tabulated listing of preventive maintenance services which must be performed by Organizational Maintenance personnel at quarterly intervals. A quarterly interval is equal to three (3) calendar months, or 250 hours of operation, whichever occurs first.

b. The item numbers are listed consecutively and indicate the sequence of minimum requirements. Refer to figure 3-6 for the Quarterly Preventive Maintenance Services.


# PREVENTIVE MAINTENANCE SERVICES

## DAILY

TM 5-3895-272-12

HUBER CORPORATION  
MODEL T58M

ROLLER, ROAD



ITEM	LUBRICATE IN ACCORDANCE WITH CURRENT LUBRICATION ORDER	PAR REF
------	--	---------

1

BATTERIES. Check electrolyte level. Fill to 3/8 inch above the plates. Check cables by hand for secure connections. In freezing weather run the engine at least one hour after adding water. (Weekly)

2-3  
3-60

2

HYDRAULIC TANK AND FILTER. Check fluid level in tank. Service hydraulic filter.

3-17

3

FIRE EXTINGUISHER. Inspect for broken seal.

2-20

4

OIL LEVEL GAGE. Check engine oil level. Add oil to proper level.

3-3

5

FAN AND HYDRAULIC PUMP BELTS. Check tension. Correct tension is 1/2 inch deflection midway between pulleys. (Weekly)

3-13  
3-17

6

COOLING SYSTEM. Check coolant level. Correct level is just below overflow.

3-12

MEC 3895-272-12/3-5 (1)

Figure 3-5. Daily preventive maintenance services.

ITEM		PAR REF								
7	<p><u>CONTROLS AND INSTRUMENTS.</u> Inspect for damage and loose mounting. With unit running, check for proper operation. Normal instrument readings are as follows:</p> <table><tr><td>Oil Pressure</td><td>20 to 30 psi</td></tr><tr><td>Temperature</td><td>160° to 180°F.</td></tr><tr><td>Ammeter</td><td>In green range</td></tr><tr><td>Converter Oil Pressure</td><td>30 to 32 psi</td></tr></table>	Oil Pressure	20 to 30 psi	Temperature	160° to 180°F.	Ammeter	In green range	Converter Oil Pressure	30 to 32 psi	2-9
Oil Pressure	20 to 30 psi									
Temperature	160° to 180°F.									
Ammeter	In green range									
Converter Oil Pressure	30 to 32 psi									
8	<p><u>FUEL SEDIMENT BOWL.</u> Remove and clean bowl. (Weekly)</p>	3-10								
9	<p><u>FUEL TANK.</u> Check fuel level.</p>	3-11								
	<p><u>NOTE: OPERATION.</u> During operation observe for any unusual noise or vibration.</p>									

MEC 3895-272-12/3-5 ②


Figure 3-5—Continued.

## PREVENTIVE MAINTENANCE SERVICES QUARTERLY

TM 5-3895-272-12

HUBER CORPORATION  
MODEL T58M

ROLLER, ROAD



ITEM	LUBRICATE IN ACCORDANCE WITH CURRENT LUBRICATION ORDER	PAR REF
1	<u>FORWARD AND REVERSE – CLUTCHES.</u> Inspect for wear and proper adjustment. Clutches engage with a definite snap when properly adjusted.	3-14
2	<u>SPRINKLER SYSTEM.</u> Inspect for leaks and proper operation.	3-18
3	<u>ENGINE OIL LEVEL.</u> Check oil level. Add or change oil in accordance with current lubrication order.	3-3
4	<u>ELECTRICAL SYSTEM.</u> Inspect magneto points for wear, pitting, and adjustment (0.015 in.). Check spark plugs for proper operation and adjustment (0.025 in.) (500 hours). Check generator brushes. Replace if worn to less than 1/2 in. in length. Check battery electrolyte. Fill to 3/8 in. above the plates. Check for loose connections and damaged wiring. Replace damaged wiring and tighten loose connections.	3-65 3-66 3-62 3-60 3-70
5	<u>HYDRAULIC SYSTEM.</u> Inspect for leaks and damage. Check hydraulic fluid level. Replace leaking lines and tighten connections.	3-17
6	<u>FIRE EXTINGUISHER.</u> Inspect for broken seal. Check for full charge by weighing.	2-20
7	<u>BELTS.</u> Inspect for wear, fraying, cuts, and proper adjustment. Proper adjustment is 1/2 in. deflection midway between pulleys.	3-13 3-17

MEC 3895-272-12/3-6 ①

Figure 3-6. Quarterly preventive maintenance services.



ITEM		PAR REF
8	<u>COOLING SYSTEM.</u> Inspect for leaks and damage. Clean the aid passages in the radiator core and check coolant level.	3-75
9	<u>FUEL SYSTEM.</u> Inspect for leaks and damage. Clean fuel strainer and sediment bowl.	3-10
10	<u>AIR CLEANER.</u> Remove and clean oil cup. Fill in accordance with current lubrication order.	3-53
11	<u>CONTROLS AND INSTRUMENTS.</u> Replace damaged instruments. Tighten loose mounting. With unit operating, check controls for proper operation. Normal instrument readings are: <div style="display: flex; justify-content: space-between; margin-top: 10px;"> <div>Oil pressure</div> <div>20 to 30 psi</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div>Temperature</div> <div>160° to 180° F.</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div>Ammeter</div> <div>In green range</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div>Converter oil pressure</div> <div>30 to 32 psi</div> </div>	3-87 to 3-108
	<u>NOTE 1. OPERATIONAL TEST.</u> During operation observe for any unusual noise or vibration.  <u>NOTE 2. ADJUSTMENTS.</u> Make all necessary adjustments during operational test.	See adjustments in index
MEC 3895-272-12/3-6 (2)		

Figure 3-6—Continued.

## Section IV. OPERATOR'S MAINTENANCE

### 3-8. General

The instructions in this section are published for the information and guidance of the operator to maintain the roller.

### 3-9. Carburetor

Adjust the carburetor as instructed on figure 3-7.

### 3-10. Fuel Pump

Service the fuel pump as instructed on figure 3-8.

### 3-11. Fuel Tank Services

- a. Service the fuel tank as instructed on figure 3-9.
- b. Flush the tank with an approved cleaning solvent.
- c. Fill the fuel tank.




Figure 3-7. Carburetor adjustment.




Figure 3-8. Fuel pump service.

### 3-12. Cooling System Service

Service the cooling system as instructed on figure 3-10.

### 3-13. Fan Belt

Adjust the fan belt as instructed on figure 3-11.

### 3-14. Forward and Reverse Clutches


Adjust the forward and reverse clutches as instructed on figure 3-12.

### 3-15. Service Brake


Adjust the service brake as instructed on figure 3-12.

### 3-16. Parking Brake

Adjust the parking brake as instructed on figure 3-13.




A. FUEL TANK FILLER CAP AND STRAINER.




B. FUEL TANK SHUT-OFF VALVE AND DRAIN COCK.

Figure 3-9. Fuel tank service.



A. RADIATOR DRAIN



B. BLOCK DRAIN

MEC 3895

Figure 3-10. Cooling system service.

### 3-17. Hydraulic System Service

a. *Hydraulic Tank Service.* Service the hydraulic tank as instructed in figure 3-14, A, B.

b. *Hydraulic Pump Drive Belt A.* Adjust the hydraulic pump drive belt as instructed in figure 3-14, C.

c. *Hydraulic Filter Service.* Service the hydraulic filter as instructed in figure 3-14, D.

draulic filter as necessary as instructed in figure 3-14, D.

### 3-18. Sprinkler System

Adjust the sprinkler system as instructed on figure 3-15.

### 3-19. Mats

Replace the cocoa mats as instructed on figure 3-16.

*Note.* When sprinkler system is not being used, hang up the mats to prevent unnecessary wear.

### 3-20. Water Tank Strainer Screen

Service the strainer screen as instructed on figure 3-17.

### 3-21. Ballast Rolls Service

Service the ballast rolls as instructed on figure 3-18.




Figure 3-12. Forward and reverse clutch and service brake adjustment.

CORRECT BELT TENSION IS 1/2 IN. DEFLECTION MIDWAY BETWEEN PULLEYS.






Figure 3-13. Parking brake adjustment.






A. FUEL TANK FILLER CAP AND STRAINER.




B. FUEL TANK SHUT-OFF VALVE AND DRAINCOCK.  
MEC 3895-272-12

Figure 3-9. Fuel tank service.



A. RADIATOR DRAIN



B. BLOCK DRAIN

MEC 3895-273-12 3-

Figure 3-10. Cooling system service.

### 3-17. Hydraulic System Service

a. *Hydraulic Tank Service.* Service the hydraulic tank as instructed in figure 3-14, A, B.

b. *Hydraulic Pump Drive Belt Adjustment.* Adjust the hydraulic pump drive belt as instructed in figure 3-14, C.

c. *Hydraulic Filter Service.* Service the h

draulic filter as necessary as instructed in figure 3-14, D.

### 3-18. Sprinkler System

Adjust the sprinkler system as instructed on figure 3-15.

### 3-19. Mats

Replace the cocoa mats as instructed on figure 3-16.

*Note.* When sprinkler system is not being used, hang up the mats to prevent unnecessary wear.


### 3-20. Water Tank Strainer Screen

Service the strainer screen as instructed on figure 3-17.


### 3-21. Ballast Rolls Service

Service the ballast rolls as instructed on figure 3-18.


CORRECT BELT TENSION IS 1.2 IN. DEFLECTION MIDWAY BETWEEN PULLEYS.




*Figure 3-11. Fan Belt Adjustment.*




*Figure 3-12. Forward and reverse clutch and service brake adjustment.*




*Figure 3-13. Parking brake adjustment.*




A. FILLER CAP.



B. TANK DRAIN AND SHUT-OFF VALVE.



C. HYDRAULIC PUMP DRIVE BELT ADJUSTMENT.




D. HYDRAULIC FILTER, ELEMENT REPLACEMENT.


MEC 3895-272-12/3-14

Figure 3-14. Hydraulic system service.






*Figure 3-15. Sprinkler system adjustment.*



A. GUIDE ROLL MAT



B. DRIVE ROLL MAT

MEC 3895-272-12/3-16

*Figure 3-16. Mat replacement.*






Figure 3-17. Water tank strainer screen service.




Figure 3-18. Ballast rolls service.

## Section V. TROUBLESHOOTING

### 3-22. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the tandem roller and its components. Each trouble symptom stated is followed by a list of probable causes of the trouble. The possible remedy recommended is described opposite the probable cause. Any trouble beyond the scope of the organizational maintenance shall be reported to direct support maintenance.

### 3-23. Engine Fails to Start or Hard to Start

Probable cause	Possible remedy
Fuel tank empty.	Fill fuel tank (para 3-6).
Fuel shutoff valve closed.	Open fuel shutoff valve (para 2-7).
Water in fuel lines.	Service fuel sediment bowl; drain fuel lines (paras 3-10, 3-11).
Plugged vent in fuel tank cap.	Open vent in cap.
Sediment bowl improperly installed; leaks air.	Inspect gasket. Install correctly (para 3-10).
Defective fuel pump.	Replace fuel pump (para 3-54).

Probable cause	Possible remedy
Magneto points defective or out of adjustment.	Adjust points or replace magneto (para 3-65).
Engine out of time.	Time magneto to engine (para 3-65).
Defective spark plugs.	Clean, inspect, adjust, and replace faulty plugs (para 3-66).
Magneto condenser shorted.	Replace magneto (para 3-65).
Overspeed governor tripped.	Reset governor (para 3-67).

### 3-24. Engine Runs Unevenly

Probable cause	Possible remedy
Defective spark plugs.	Clean, adjust, or replace plugs (para 3-66).
Carburetor out of adjustment.	Adjust carburetor (para 3-55).
Magneto points defective or out of adjustment.	Adjust points or replace magneto (para 3-65).
Engine speed governor out of adjustment.	Adjust governor (para 3-58).
Air leaks in intake manifold.	Tighten loose manifold nuts (para 3-83).
Leaking head gasket.	Replace gasket (para 3-82).
Cylinder compression uneven.	Adjust valves (para 3-84).

**3-25. Engine Lacks Power**

Probable cause	Possible remedy
Magneto out of time.	Time magneto to engine (para 3-65).
Clogged fuel strainer.	Service fuel strainer (para 3-54).
Poor fuel.	Use proper grade fuel.
Air leak in intake system.	Tighten manifold nuts, inspect air cleaner connections for tightness (paras 3-53, 3-83).
Engine speed governor set too low.	Adjust governor (para 3-58).

**3-26. Engine Overheats**

Probable cause	Possible remedy
Loss of coolant.	Replenish coolant. Check for leaks (para 3-12).
Fan belt slipping.	Adjust fan belt (para 3-13).
Air flow through radiator obstructed.	Clean radiator fins.
Engine overloaded.	Reduce load.
Crankcase oil level too low.	Check and replenish oil (para 3-3).
Defective thermostat.	Replace thermostat (para 3-75).
Clogged radiator.	Flush radiator, or replace (para 3-75).
Timing incorrect.	Time engine (para 3-65).
Back pressure in exhaust line.	Inspect exhaust system; replace plugged muffler (para 3-85).

**3-27. Engine Makes Unusual Noises**

Probable cause	Possible remedy
Valves out of adjustment.	Adjust valves (para 3-84).

**3-28. Low Oil Pressure**

Probable cause	Possible remedy
Crankcase oil low.	Check oil level and replenish as needed (para 3-3).
Oil too light; diluted.	Use proper grade oil, or change oil (para 3-3).
Oil pressure gauge or line faulty.	Replace faulty gauge or line (para 3-95).

**3-29. High Oil Consumption**

Probable cause	Possible remedy
Oil level too high in crankcase.	Check oil level. Fill to proper level (para 3-3).
Wrong grade oil used.	Use proper grade oil (para 3-3).
Clogged crankcase breather pipe.	Clean out breather pipe.

**3-30. Excessive Fuel Consumption**

Probable cause	Possible remedy
Carburetor out of adjustment.	Adjust carburetor (para 3-9).
Carburetor float sticks.	Replace carburetor (para 3-55).
Timing incorrect.	Time engine (para 3-65).

**3-31. Engine Stops Suddenly**

Probable cause	Possible remedy
Fuel tank empty	Fill fuel tank (para 3-11).
Restriction in fuel line.	Clean out fuel line (para 3-57).
Magneto capacitor shorted.	Replace capacitor (para 3-65).
Magneto coil burned out.	Replace magneto (para 3-65).
Overspeed governor tripped.	Reset and adjust governor (para 3-67).

**3-32. Engine Surges (Speed Unsteady)**

Probable cause	Possible remedy
Engine speed governor spring may need slight increase in tension.	Adjust governor (para 3-58).
Engine speed governor worn.	Replace governor (para 3-58).

**3-33. Battery-Generator Indicator Will Not Indicate in Green Range**

Probable cause	Possible remedy
Fan belt slipping.	Adjust fan belt (para 3-13).
Loose or broken connection in generator circuit.	Check out wiring. Repair wiring as required.
Defective regulator.	Replace regulator (para 3-63).
Generator brushes worn out.	Replace brushes (para 3-62).
Defective generator.	Replace generator (para 3-62).
Defective indicator.	Replace indicator (para 3-99).

**3-34. Battery-Generator Indicator Reads in Low, Red Range**

Probable cause	Possible remedy
Short in wiring or accessory.	Inspect wiring and electrical components for evidence of shorting, overheating. Repair as necessary.
Shorted battery cell or cells.	Replace battery (para 3-60).

### 3-35. Converter Oil Temperature Excessive

Probable cause	Possible remedy
Wrong gear speed used.	Use lower gear.
Operator stalls converter for too long time.	Refer to operating instructions.
Low oil supply.	Check oil level in torque converter and replenish as needed (para 3-4).

### 3-36. Converter Oil Pressure Too Low

Probable cause	Possible remedy
Oil level too low in converter.	Check oil level in converter and replenish (para 3-4).
Defective gage or sending unit.	Replace gage or sending unit (paras 3-100, 3-104).

### 3-37. Hydraulic Pump Noisy

Probable cause	Possible remedy
Air getting into suction line.	Check oil level in tank (paras 3-3, 3-17).
Hydraulic pump worn.	Replace hydraulic pump (para 3-113).

### 3-38. Guide Roll Steers Too Slowly

Probable cause	Possible remedy
Variable speed steering valve set too low.	Refer to operating instructions (para 2-11c(4)).
Engine idling.	Use adequate engine speed.
Low hydraulic pressure.	Adjust regulating valve to specified pressure (para 3-114).
Defective steering control valve.	Replace steering control valve (para 3-114).

### 3-39. Guide Roll Moves From Position

Probable cause	Possible remedy
Variable speed control valve set too low.	Refer to operating instructions (para 2-11c(4)).
Defective steering control valve.	Replace steering control valve (para 3-114).

### 3-40. Steering is Spongy

Probable cause	Possible remedy
Air in hydraulic lines.	Bleed lines at highest point. Exercise cylinder and bleed again to expel trapped air (para 3-110).

### 3-41. Guide Roller Slides: Roller Turns Poorly

Probable cause	Possible remedy
Dirt accumulation jams roll.	Clean dirt from rollers.

### 3-42. Rolls Become Grooved

Probable cause	Possible remedy
Extremely hard rock fill lodges behind scrapers.	Keep scrapers cleaned out when rolling this type of material.

### 3-43. Guide Roll Makes Depression in Asphalt after Stopping or Changing Direction

Probable cause	Possible remedy
Yoke kingpin bearings out of adjustment or damaged.	Adjust guide yoke, or replace damaged bearings (para 3-137).
Improper operator technique.	Refer to operating instructions for rolling pavement (paras 2-11, 2-14).

### 3-44. Service Brake or Parking Brake Fails to Hold

Probable cause	Possible remedy
Brake out of adjustment.	Adjust brakes (paras 3-15, 3-16).
Grease-soaked discs.	Clean discs with cleaning solvent.

### 3-45. Roller Hesitates or Does Not Move Forward or Backward

Probable cause	Possible remedy
Clutch, or clutches slipping.	Adjust clutches (para 3-14).
Torque converter oil level low.	Check oil level in converter. Replenish as necessary (para 3-3).

### 3-46. Gears Clash when Shifting

Probable cause	Possible remedy
Improper operator technique.	Roller must be stopped when changing gear ratio. Refer to operating instructions.

## Section VI. RADIO INTERFERENCE SUPPRESSION

### 3-47. Definitions

a. *Interference.* The term "interference" as used herein applies to electrical disturbances in the radio frequency range which are gen-

erated by the tandem roller and which may interfere with the proper operation of radio receivers or other electrical equipment or enable the enemy to locate the equipment.

*b. Interference Suppression.* The term "interference suppression" as used herein applies to the methods used to eliminate or effectively reduce radio interference generated by the tandem roller.

### 3-48. General Methods Used to Attain Proper Suppression

Essentially, suppression is attained by providing a low resistance path to ground for the stray currents. The methods used to attain suppression include shielding the ignition and high-frequency wires, grounding the frame with bonding straps, and using capacitors and resistors where necessary.

### 3-49. Interference Suppression Components

*a.* Primary suppression components used to overcome the electrical disturbances generated by the tandem roller consist of internal-toothed lockwashers installed under the heads and under the nuts of the attaching hardware to the side of roller frame.

*b.* Secondary suppression components, which are incidental to the primary, include a

condenser in the magneto assembly. Also, grounding straps on the engine and instrument panel help in this function.

### 3-50. Replacement of Suppression Components

As indicated above, the components which may require replacement are the internal-toothed lockwashers under the heads of bolts and under nuts in any place where electrical components are bolted, and under grounding straps and electrical system leads. Also, the magneto assembly contain a condenser, which may require replacement if the problem of interference is experienced.

### 3-51. Testing of Radio Interference Suppression Components

Test the capacitors for leaks and shorts on a capacitor tester; replace defective capacitors. If test equipment is not available and interference is indicated, isolate cause by the trial-and-error method of replacing each capacitor in turn until the cause of interference is located and eliminated.

## Section VII. ENGINE FUEL SYSTEM

### 3-52. Description

The fuel system consists of a carburetor, fuel pump, and strainer assembly, air cleaner, fuel tank, lines, and fittings. Fuel is delivered from the fuel tank to the carburetor by the fuel pump. The air cleaner prevents dirt, dust, and foreign material from entering the engine. A centrifugal type governor maintains a constant engine speed.

### 3-53. Air Cleaner

*a. Removal.* Remove the air cleaner from the roller as instructed on figure 3-19.

*b. Disassembly.*

- (1) Remove the clamp (4, fig. 3-20), outer oil cup (3), and inner oilcup (2) from the body (1).
- (2) Remove the two bands (5) from the body (1).

*c. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.

- (2) Inspect all parts for defects and damage. Repair or replace defective or damaged parts.

*d. Reassembly.*

- (1) Install the two bands (5) on the body (1).
- (2) Install the inner oil cup (2), outer oil cup (3), and the clamp (4) on the body (1).

*e. Installation.* Install the air cleaner on the roller in reverse of the instructions on figure 3-19.

### 3-54. Fuel Pump

*a. Removal.* Remove the fuel pump from the engine as instructed on figure 3-21.

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the fuel pump for wear, leaks, defects, and damage.




Figure 3-19. Air cleaner, removal and installation.

- (3) Replace a worn, damaged, or defective fuel pump.

*c. Installation.* Install the fuel pump in reverse of the instructions on figure 3-21. Put new gasket in between pump-flange and pad.

### 3-55. Carburetor

*a. Removal.*

- (1) Disconnect the control linkage from the carburetor.
- (2) Remove air cleaner hose from carburetor.
- (3) Remove the carburetor as instructed on figure 3-22.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean the carburetor with approved cleaning solvent.
- (2) Perform the service, as required, on the carburetor (para d).

- (3) Inspect the carburetor for damage, loose screws, wear in the throttle valve shaft, and other defects.
- (4) Replace a defective carburetor.

*c. Installation.*

- (1) Install the carburetor in reverse of the instructions on figure 3-22. Put in new gasket between flange and mounting pad.
- (2) Connect the control linkage to the carburetor.
- (3) Connect air cleaner hose to carburetor.
- (4) Adjust the carburetor (para 3-9).

*d. Service.*

- (1) Service the carburetor as instructed on figure 3-22.
- (2) Adjust the carburetor (para 3-9).

### 3-56. Fuel Level Sending Unit

*a. Removal.* Remove the fuel level sending unit as instructed on figure 3-23.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean the sending unit with an approved cleaning solvent.
- (2) Inspect the float for evidence of fuel soaking.
- (3) Inspect for poor electrical connections, damaged wiring, and such. Replace a defective sending unit.

*c. Installation.* Install the fuel level sending unit in reverse of the instructions on figure 3-23.


### 3-57. Fuel Tank

*a. Removal.* Remove the fuel tank as instructed on figure 3-24.

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent, including fuel lines.
- (2) Inspect the tank and line for leaks and damage. Replace leaking or damaged parts.

*c. Installation.* Install the fuel tank in reverse of the instructions on figure 3-24.



MEC 3895-272-12/3-20

- 1 Body
- 2 Inner oil cup
- 3 Outer oil cup
- 4 Clamp
- 5 Band (2)

- 6 Screw (4)
- 7 Nut (4)
- 8 Washer (4)
- 9 Clamp (2)
- 10 Hose

Figure 3-20. Air cleaner, exploded view.

### 3-58. Engine Speed Governor

a. Adjustment. (figure 3-25, A)

- (1) Disconnect the hand throttle linkage from the governor lever A and

place the hand throttle control in the fully open position (rearward).

- (2) Disconnect the governor-to-carburetor rod from lever B.






Figure 3-21. Fuel pump, removal and installation.

- (3) Loosen jam nuts and back out governor stop screws 1 and 2.
- (4) With hand throttle lever and the governor lever A in the fully open position, adjust the hand throttle linkage until the pin holes are aligned. Connect the linkage.
- (5) Place the hand throttle control in the idle position and the carburetor throttle lever against the idle stop. Adjust the governor-to-carburetor rod ball joint to just slide into the lever B; then lengthen rod two turns and tighten locknut. Connect rod to lever B.
- (6) Start the engine in the idle position and check idle rpm. Adjust the carburetor throttle stop screw to obtain 500—700 rpm. Loosen locknut A and tighten nut B until the idle rpm

starts to increase; backoff nut B slightly and tighten locknut A.

- (7) Advance the hand throttle control to the full open position and check rpm. If rpm is low (below 2100), loosen locknut A and tighten locknut B until 2100 rpm is attained. Return throttle to idle position and recheck idle rpm; if high, lengthen the governor-to-carburetor rod until 500 to 700 rpm is attained.

*Note.* If engine surges at idle speed, lengthen the governor-to-carburetor rod slightly.

*Note.* Difficulty may be experienced obtaining both the specified high and low rpm settings due to peculiarities within a particular governor. In this case, some compromise may be necessary in the low rpm setting.




Figure 3-22. Carburetor, removal, installation, and service.




Figure 3-23. Fuel level sending unit, removal and installation.

- (8) After governor is adjusted, open hand throttle and turn lockcrew 1 in until it just touches stop. Tighten jam nut. Close hand throttle and turn in lockcrew 2 until it just touches stop. Tighten jam nut. Press button on overspeed governor to reset.

b. *Removal.* Remove the engine speed governor as illustrated on figure 3-25, B.

c. *Cleaning, Inspection, and Repair.*

- (1) Clean the governor with a cloth and approved cleaning solvent.
- (2) Inspect the governor for damaged or excessively worn drive gear teeth.
- (3) Check governor for excessive wear in lever shafts and other defects.
- (4) Replace a defective governor.

d. *Installation.*

- (1) Install the engine speed governor in reverse of the instructions on figure 3-25, B.
- (2) Adjust the engine speed governor (para a.).






Figure 3-24. Fuel tank, removal and installation.





A. ADJUSTMENT.



B. REMOVAL AND INSTALLATION

MEC 3895-272-12/3-25

Figure 3-25. Engine speed governor, adjustment, removal, and installation.

## Section VIII. ELECTRICAL SYSTEM

### 3-59. Description

The electrical system of the roller is 24 volt, negative ground. It consists of a generator, generator regulator, starter and solenoid, gages and wiring, and two 12-volt batteries. Power is supplied by the batteries for starting the engine and is replenished by the generator. The current and voltage delivered by the generator is controlled by the regulator to maintain the batteries at full charge. The ignition system consists of a magneto, spark plugs, and shielded wiring.

### 3-60. Batteries and Battery Cables

a. *Removal.* Remove the batteries and battery cables as instructed on figure 3-26.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the batteries for cracks, loose or broken terminals, and other damage. Test cells with a suitable tester and check specific gravity. See table 2-1, Chapter 2, Section I. Replace defective batteries.

- (3) Inspect cables for fraying, corrosion, and damage. Replace defective cables.

c. *Installation.* Install the batteries and cables in reverse of the instructions on figure 3-26.

### 3-61. Battery Frame Assembly

a. *Removal.*

- (1) Remove the batteries (para 3-60).
- (2) Remove the battery frame assembly as instructed on figure 3-26.

b. *Cleaning, Inspection, and Repair.*

- (1) Steam clean the battery frame. Remove all corrosion from frame.
- (2) Inspect the frame for cracks, broken weld, or other damage.
- (3) Repair a damaged frame by welding and/or straightening.

c. *Installation.*

- (1) Install the battery frame in reverse of the instructions on figure 3-26.
- (2) Install the batteries (para 3-60).




Figure 3-26. Batteries and battery cables, removal and installation.

### 3-62. Generator

a. *Removal.* Remove the generator as instructed on figure 3-27.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the brushes for wear and damage. Brushes that have worn to 1/2 inch or less in length should be replaced. Replace brushes as necessary. Refer to paragraph d.
- (3) Inspect the generator for damage and proper operation. Replace a damaged or defective generator.

c. *Installation.*

- (1) Install the generator and drive belt in reverse of the instructions on figure 3-27.
- (2) Adjust the generator drive fan belt (para 3-13).

d. *Generator Brush Replacement.*

- (1) Remove cover band from generator (fig. 3-27).
- (2) Remove brushes as instructed on figure 3-28.
- (3) Inspect the commutator for severe pitting, grooving, discoloration, or high mica between segments.
- (4) Install new brushes in reverse of the instructions on figure 3-28.




Figure 3-27. Generator, removal and installation.

- (5) Seat new brushes preferably by running the generator and holding a commutator stone against the commutator for a minute or two. An alternate method is to place a strip of sandpaper face up around the commutator and under the brushes. Rotate the armature by hand until the brushes conform to the shape of the commutator.

### 3-63. Generator Regulator

a. *Removal.* Remove the generator regulator as instructed on figure 3-29.

b. *Cleaning and Inspection.*

- (1) Clean the generator regulator with a cloth and approved cleaning solvent.
- (2) Inspect the regulator for defects and damage. Replace a defective or damaged regulator.




Figure 3-28. Generator brush replacement.

c. *Installation.* Install the generator regulator in reverse of the instructions on figure 3-29.

### 3-64. Starter and Solenoid

a. *Removal.* Remove the starter and solenoid as instructed on figure 3-30.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the starter for wear, defects, and damage. Replace a worn, defective, or damaged starter.
- (3) Inspect the solenoid switch for defects and damage. Check for continuity between terminals with switch in engaged position. Replace a defective solenoid switch.

c. *Installation.* Install the starter and solenoid in reverse of the instructions on figure 3-30.




Figure 3-29. Generator regulator, removal and installation.

### 3-65. Magneto

a. *Removal.*

- (1) Disconnect the ground wire (fig. 3-31).
- (2) Remove the magneto from the engine as instructed on figure 3-31.

b. *Disassembly.*

- (1) Remove four screws which hold terminal block in end cap (fig. 3-32 A).
- (2) Remove leads and terminal block.
- (3) Remove four screws, end cap and gasket.

c. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent. Dry thoroughly.
- (2) Inspect the magneto for wear, defects, and damage. Replace a worn, defective, or damaged magneto.
- (3) Inspect the contact points for deep pitting or burning. Replace points as instructed on figure 3-32 B.




Figure 3-30. Starter and solenoid, removal and installation.




Figure 3-31. Magneto, removal and installation.

- (4) Test the capacitor for an open or short-circuited condition. Replace if defective.

d. *Contact Point Adjustment.* Adjust the contact points as instructed on figure 3-32 C.

e. *Reassembly.* Install end cap terminal block and capacitor.

f. *Timing and Installation.* Align the timing marks as shown on figure 3-33. Install the magneto in reverse of the instructions on figure 3-31.

### 3-66. Spark Plugs and Cables

a. *Removal.* Remove the spark plugs and cables as instructed on figure 3-34.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Clean and test spark plugs with a suitable tester. Replace defective spark plugs.
- (3) Check spark plug gap. Correct gap is 0.025 inches for standard plugs; 0.035 for resistor type plugs.
- (4) Inspect cables for frayed or damaged insulation, broken leads, and damaged connectors. Replace defective cables.

c. *Installation.* Install the spark plugs and cables in reverse of the instructions of figure 3-34.

### 3-67. Overspeed Governor

a. *Removal.* Remove the overspeed governor as instructed on figure 3-35.

b. *Cleaning, Inspection and Repair.*

- (1) Clean the overspeed governor with a cloth and cleaning solvent.
- (2) Inspect the governor for damage, loose components, rough turning shaft, or other defects. Replace a defective governor.

c. *Installation.* Install the overspeed governor in reverse of the instructions on figure 3-35.


d. *Adjustment.* Adjust the overspeed governor, if necessary, as instructed on figure 3-36.

### 3-68. Floodlamps


a. *Removal.* Remove the floodlamps as instructed on figure 3-37.

b. *Disassembly.*

- (1) Remove the screw (6, Fig. 3-38) and molding (5) from the body (1).



USE A FEELER GAGE AND CHECK THE GAP BETWEEN THE CONTACT POINTS AT THE FULLY OPEN POSITION. THE GAP SHOULD BE 0.015 IN.



MEC 3895-273-12/3-35

Figure 3-32. Magneto contact points, replacement and adjustment.






Figure 3-33. Magneto timing marks.




Figure 3-34. Spark plugs and cables, removal and installation.

Figure 3-35. Overspeed governor, removal and installation.




Figure 3-36. Overspeed governor, adjustment.

- (2) Remove the screw (6) and molding (7), disconnect the receptacle from the sealed beam (3) and remove the sealed beam.
- (3) Remove the ring (4) from the body (1) and remove the nut (10), washer (9), and the plate (8) from the body (1).
- c. Cleaning and Inspection.*
  - (1) Clean all parts with an approved cleaning solvent.
  - (2) Inspect all parts for damage and proper operation. Replace defective parts.
- d. Reassembly.*
  - (1) Install the ring (4), molding (5), and screw (6) on the body (1).
  - (2) Connect the receptacle to the sealed beam (3) and insert the sealed beam unit in the body (1).
  - (3) Install the molding (7) and screw (6) on the ring (4).

*e. Installation.* Install the floodlamps in reverse of the instructions on figure 3-37.

### 3-69. Circuit Breakers

- a. Removal.* Remove the circuit breakers from the roller as instructed on figure 3-39.
- b. Cleaning, Inspection, and Repair.*
  - (1) Clean the breakers with a cloth and cleaning solvent.
  - (2) Inspect the breakers for continuity, and for signs of damage.
  - (3) Replace faulty breakers.
- c. Installation.*
  - (1) Install the circuit breakers and panel in reverse of the instructions on figure 3-39.
  - (2) Refer to the wiring diagram (fig. 1-4) and connect the leads.

### 3-70. Wiring and Wiring Harness

*a. Repair.* If an electrical lead becomes broken, insulation torn or deteriorated, repair by splicing a new lead to the old, affixing terminals as required. If a wire fails inside the wiring harness, run a new wire along the outside and tape wire to the harness.

#### *b. Removal.*

- (1) Disconnect wire leads from the switches, lights, and other components of the roller.
- (2) Remove hold-down clamps and lift the wiring harness from the roller.

#### *c. Cleaning, Inspection, and Repair.*

- (1) Clean the wiring harness with a cloth dampened in cleaning solvent.
- (2) Inspect the harness for deteriorated insulation, broken leads, and other damage.
- (3) Repair harness as described in paragraph *a.* above, or replace harness assembly.

#### *d. Installation.*

- (1) Install the wiring harness on the roller, securing it to the frame with the hold down clamps.
- (2) Refer to the wiring diagram (fig. 1-4) and connect the leads to the instruments, switches and electrical components of the roller.





Figure 3-37. Floodlamps, removal and installation.



MEC 3895-273-12/3-41

- |                  |           |           |        |
|------------------|-----------|-----------|--------|
| 1 Body           | 5 Molding | 9 Washer  | 13 Nut |
| 2 Receptacle     | 6 Screw   | 10 Nut    |        |
| 3 Seal beam unit | 7 Molding | 11 Bolt   |        |
| 4 Ring           | 8 Plate   | 12 Washer |        |

Figure 3-38. Floodlight, exploded view.






Figure 3-39. Circuit breaker, removal and installation.

## Section IX. LUBRICATION SYSTEM

### 3-71. Description

The lubrication system of the engine consists of an oil pump, oil filter, lines, and fittings. Oil is pumped from the engine crankcase by the oil pump through internal passages in the cylinder block to the crankshaft, camshaft, and timing gears. The oil then passes through the oil filter and returns to the crankcase. An oil pressure regulator valve located in the side of the cylinder block maintains a pressure of between 20 and 30 psi.

### 3-72. Oil Filter, Lines, and Fittings

a. *Removal.* Remove the oil filter, lines, and fittings as instructed on figure 3-40.

b. *Disassembly.*

- (1) Remove the nuts (27), (fig. 3-41), washers (28), screws (32), washers (31), and bracket (33) from the filter (7).
- (2) Remove the screw (3), gasket (2), cover (1), gasket (4), spring (34), and element (5) from the body (7).

- (3) Remove the nuts (30), washers (29), screws (6), and straps (8), from the body (7).

- (4) Remove the connector (9), connector (22), plug (26), tee (25), bushing (23), and nipple (24) from the body (7).

c. *Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for defects and damage. Replace defective or damaged parts.

d. *Reassembly.*

- (1) Install the connector (22), nipple (24), bushing (28), tee (25), plug (26), and connector (9) on the body (7).
- (2) Install the filter element (5) and spring (34) in the body (7) and install the gasket (4), cover (1), gasket (2), and screw (3) on the body (7).




Figure 3-40. Oil filter, removal and installation.

- (3) Install the straps (8) on the body (7) and secure with the screws (6), washers (29), and nuts (30).

- (4) Position the bracket (33) on the body (7) and secure with the screws (32), washers (28 and 31), and nuts (27).

*e. Installation.* Install the oil filter, lines, and fittings in reverse of instructions on figure 3-40.

### 3-73. Engine Oil Pressure Regulator Valve


*a. Removal.* Remove the oil pressure regulator valve from the engine as instructed on figure 3-42.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts in approved cleaning solvent.
- (2) Inspect the valve for damage or evidence of wear where valve sets in block.
- (3) Inspect the spring for weak or broken condition. If engine is not badly worn, low engine oil pressure can be caused by a defective spring. Normal oil pressure under load should be 20—30 psi.

- (4) Replace defective parts.

*c. Installation.* Install the oil pressure regulator valve in the engine block in reverse of the instructions on figure 3-42.



1 Cover  
2 Gasket  
3 Screw

4 Gasket  
5 Element  
6 Screw

7 Body  
8 Strap  
9 Connector

10 Nut  
11 Tube  
12 Nut

Figure 3-41. Oil filter and lines, exploded view.

MEC 3895-273-12/3-44

13 Elbow	19 Plug	25 Tee	31 Washer
14 Nut	20 Tube	26 Plug	32 Screw
15 Elbow	21 Nut	27 Nut	33 Bracket
16 Elbow	22 Connector	28 Washer	34 Spring
17 Nipple	23 Bushing	29 Washer	
18 Tee	24 Nipple	30 Nut	

Figure 3-41—Continued.




Figure 3-42. Engine oil pressure regulator valve, removal and installation.

## Section X. ENGINE COOLING SYSTEM

### 3-74. Description

The engine cooling system consists of a radiator, water pump, fan, hose, and thermostat. The radiator is protected by a grille and shroud. Coolant is circulated through the system by the water pump, and cooled by the fan as it passes through the radiator core. The thermostat prevents circulation of the coolant until the temperature reaches 160° to 180° F., thus providing a shorter warm-up period for the engine.


### 3-75. Radiator

a. *Removal.* Remove the grille and radiator as instructed on figure 3-43.


b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the radiator for leaks and damage. Replace a leaking or damaged radiator.


c. *Installation.* Install the radiator and grille in reverse of the instructions on figure 3-43.



A. BAFFLE REMOVAL



B. GRILLE REMOVAL AND UPPER CONNECTIONS



C. LOWER CONNECTIONS

MEC 3895-272-12/3-43

Figure 3-43. Radiator, removal and installation.

### 3-76. Fan Belt

#### a. Removal.

- (1) Remove the hydraulic pump drive belt (para 3-112).

- (2) Remove the grille (para 3-75).

- (3) Remove the fan belt as instructed on figure 3-44.




Figure 3-44. Fan belt, removal and installation.

*b. Cleaning and Inspection.*

- (1) Clean the fan belt with an approved cleaning solvent.
- (2) Inspect the fan belt for wear, breaks, and fraying. Replace a defective or worn belt.

*c. Installation.*

- (1) Install the fan belt in reverse of the instructions on figure 3-44.
- (2) Adjust the fan belt (para 3-13).
- (3) Install the hydraulic pump drive belt (para 3-112).
- (4) Install the grille (para 3-75).

**3-77. Fan Assembly**

*a. Removal.*

- (1) Remove the fan belt (para 3-76).
- (2) Remove the fan assembly as instructed on figure 3-45.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.

- (2) Inspect the fan assembly for bent or broken blades, loose rivets, and other damage.
- (3) Straighten blades and tighten loose rivets. Replace a badly damaged fan assembly.

*c. Installation.*

- (1) Install the fan assembly in reverse of the instructions on figure 3-45.
- (2) Install the fan belt (para 3-76).

**3-78. Water Pump**

*a. Removal.*

- (1) Remove the fan assembly (para 3-77).
- (2) Remove the water pump as instructed on figure 3-46.

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the water pump for leaks, damage, wear, and defects. Replace a leaking or defective pump.

*c. Installation.*

- (1) Install the water pump in reverse of the instructions on figure 3-46.
- (2) Install the fan assembly (para 3-77).




Figure 3-45. Fan assembly, removal and installation.






Figure 3-46. Water pump, removal and installation.

### 3-79. Thermostat and Thermostat Housing

a. *Removal.* Remove the thermostat and thermostat housing as instructed on figure 3-47.

b. *Cleaning, Inspection, and Test.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the housing for cracks and defects. Replace defective housing.
- (3) Inspect the thermostat for damage and defects. Test the thermostat by submerging it in a container of water over a suitable heating device. Heat water and check temperature at which the thermostat begins to open. The thermostat should begin to open at 160° F. If the thermostat will not meet these requirements, it must be replaced.

c. *Installation.* Install the thermostat and thermostat housing in reverse of the instructions on figure 3-47.

### 3-80. Water Temperature Sending Unit

a. *Removal.* Remove the water temperature sending unit from the engine as instructed on figure 3-48.

b. *Cleaning, Inspection, and Repair.*

- (1) Clean the water temperature sending unit, removing any scale and rust from the element.
- (2) Inspect the unit for damage and proper operation. Replace a defective unit.

c. *Installation.* Install the water temperature sending unit in the engine in reverse of the instructions on figure 3-48.




Figure 3-47. Thermostat and thermostat housing, removal and installation.




Figure 3-48. Water temperature sending unit, removal and installation.



## Section XI. ENGINE

## 3-81. Description

The engine is a Continental, Model FS-244, 6 cylinder, L-head, liquid cooled type. The cylinder head is a flat type mounted on the cylinder block by capscrews. The valves are located in the cylinder block directly under the cylinder head. Covers located under the intake and exhaust manifolds provide access to the valve adjusting mechanism. The intake and exhaust manifolds located on the upper right side of the engine provides for the entry of fuel from the carburetor and expulsion of exhaust gases.

## 3-82. Cylinder Head

*a. Removal.*

- (1) Drain the radiator (para 3-75).
- (2) Disconnect upper radiator hose and by-pass tube (figure 3-47).
- (3) Remove oil filter (para 3-72).
- (4) Remove overspeed governor (para 3-67).
- (5) Remove cylinder head as instructed on figure 3-49.

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Clean all traces of old gasket from cylinder head and top of engine block.
- (3) Inspect all parts for defects and damage. Replace defective or damaged parts.

*c. Installation.*

- (1) Use a new head gasket and install the cylinder head in reverse of the instructions on figure 3-49.
- (2) Tighten the cylinder head in the numbered sequence illustrated in figure 3-50.

*Note.* Refer to Chapter 1, paragraph 1-4b. (8) for correct torquing data for cylinder head attaching hardware.

- (3) Install and connect components in reverse order as listed in *a.* (1) through (4) above.

## 3-83. Manifold Assembly

*a. Removal.*

- (1) Remove the carburetor (para 3-55).
- (2) Remove the exhaust pipe (para 3-86).
- (3) Remove the manifold assembly as instructed on figure 3-51.

*b. Disassembly.*

- (1) Remove the nuts (3, fig. 3-52), washers (2), and separate the exhaust manifold (1) from the intake manifold (11). Remove the gasket (8).
- (2) Remove the valve (21) from the shaft (20).
- (3) Observe and mark position of weight (19) on manifold (1). Remove the nut (17), washer (15), and weight assembly (19) from the exhaust manifold (1). Remove the stud (18) and bushings (16) from the manifold (1).
- (4) Remove the plugs (10, 12, and 14) from the intake manifold (11).
- (5) Remove the studs (9 and 13) from the intake manifold (11).

*c. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Replace worn, defective, or damaged parts.

*d. Reassembly.*

- (1) Install the studs (9 and 13) and plugs (10, 12, and 14) in the intake manifold (11).
- (2) Install the stud (18) and bushings (16) in the exhaust manifold (1).
- (3) Install the valve (21), weight and shaft assembly (19, 20), washer (15), and nut (17) on the exhaust manifold (1). Place weight in the position from which removed from manifold. Tighten nut (17).
- (4) Place a new gasket (8) over the studs (4) and position the exhaust




Figure 3-49. Cylinder head, removal and installation.

manifold (1) on the intake manifold (11), secure with the washers (2) and nuts (3).

*e. Installation.*

- (1) Install the manifold assembly in reverse of the instructions on figure 3-51.
- (2) Install the carburetor (para 3-55).
- (3) Install the exhaust pipe (para 3-86).

### 3-84. Valves

*a. Removal.* Remove the valve cover as instructed on figure 3-53.

*b. Adjust the valves as instructed on figure 3-54.*

*c. Install the valve cover in reverse of the instructions on figure 3-53.*

### 3-85. Muffler

*a. Removal.* Remove the muffler as instructed on figure 3-55.

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.

- (2) Inspect the muffler for defects and leaks. Replace a defective or leaking muffler.

*c. Installation.* Install the muffler in reverse of the instructions on figure 3-55.

### 3-86. Exhaust Pipe

*a. Removal.*

- (1) Remove the muffler (para 3-85).
- (2) Remove the exhaust pipe as instructed on figure 3-56.

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the exhaust pipe for holes, rust, and other damage. Replace a defective exhaust pipe.

*c. Installation.*

- (1) Install the exhaust pipe in reverse of the instructions on figure 3-56.
- (2) Install the muffler (para 3-85).

### 3-87. Crankshaft Pulley

*a. Removal.*


- (1) Remove six (6) nuts and lockwashers that secure the front dust shield to frame. Remove shield from frame. Dust shield is located immediately behind the guide roll.
- (2) Remove the drive and hydraulic pump belts (paras 3-76 and 3-112).
- (3) Remove the crankshaft pulley as instructed on figure 3-57.

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Replace worn, defective, or damaged parts.


*c. Installation.*

- (1) Install the crankshaft pulley in reverse of the instructions on figure 3-57.
- (2) Install the drive and hydraulic pump belts (paras 3-76 and 3-112).
- (3) Secure the dust shield to the frame with six (6) nuts and lockwashers.




EMC 2805-210-12/33

*Figure 3-50. Cylinder head tightening sequence.*




*Figure 3-51. Manifold assembly, removal and installation.*



MEC 3895-273-12/3-55


- |                    |                    |            |           |
|--------------------|--------------------|------------|-----------|
| 1 Exhaust manifold | 8 Gasket           | 15 Washer  | 22 Nut    |
| 2 Washer           | 9 Stud             | 16 Bushing | 23 Washer |
| 3 Nut              | 10 Plug            | 17 Nut     | 24 Washer |
| 4 Stud             | 11 Intake Manifold | 18 Stud    | 25 Nut    |
| 5 Gasket           | 12 Plug            | 19 Weight  | 26 Washer |
| 6 Washer           | 13 Stud            | 20 Shaft   |           |
| 7 Nut              | 14 Plug            | 21 Valve   |           |

*Figure 3-52. Manifold assembly, exploded view.*



*Figure 3-53. Valve cover, removal and installation.*

BOTH INTAKE AND EXHAUST VALVE CLEARANCE IS 0.014 IN.



MEC 3895-273-12/3-57

*Figure 3-54. Valve adjustment.*




Figure 3-55. Muffler, removal and installation.




Figure 3-57. Crankshaft pulley, removal and installation.




Figure 3-56. Exhaust pipe, removal and installation.

## Section XII. CONTROLS AND INSTRUMENTS

### 3-88. Description

The operating controls of the roller consists of the steering lever, forward and reverse clutch lever, gear shift lever, hand brake lever, foot brake pedal, sprinkler pedals and related linkage. All the controls are located on the operator's platform and connected to the related component by linkage or cables.


The instruments and gages are located on the instrument panel along side the operator.

### 3-89. Service Brake Pedal and Linkage

a. *Removal.* Remove the foot brake pedal and linkage as instructed on figure 3-58.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.



A. BRAKE PEDAL AND UPPER CONNECTION.



B. BOTTOM END OF BRAKE LINKAGE.

MEC 3895-272-12 3-58

Figure 3-58. Service brake pedal and linkage, removal and installation.

- (2) Inspect all parts for wear, damage, and defects. Replace worn, damaged, or defective parts.

*c. Installation.*

- (1) Install the service brake pedal and linkage in reverse of the instructions on figure 3-58.
- (2) Adjust the service brake (para 3-15).

### 3-90. Parking Brake Lever and Linkage

*a. Removal.* Remove the parking brake lever and linkage as instructed on figure 3-59.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, damage, and defects. Replace worn or damaged parts.

*c. Installation.*

- (1) Install the parking brake lever and linkage in reverse of the instructions on figure 3-59.
- (2) Adjust the parking brake (para 3-16).

### 3-91. Gearshift Lever and Linkage

*a. Removal.* Remove the gearshift lever and linkage as instructed on figure 3-60.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Replace worn, defective, or damaged parts.

*c. Installation.* Install the gearshift lever and linkage in reverse of the instructions on figure 3-60.

### 3-92. Forward and Reverse Clutch Lever and Linkage

*a. Removal.* Remove the forward and reverse clutch lever and linkage as instructed on figure 3-60.

*b. Cleaning, Inspection, and Repair.*


- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Repair or replace worn, defective, or damaged parts.

*c. Installation.* Install the forward and reverse clutch lever in reverse of the instructions on figure 3-60.


### 3-93. Steering Valve Lever and Linkage

*a. Removal.* Remove the steering valve lever, and linkage as instructed on figure 3-61.






A



B



C

MEC 3895-272-12 3-59

Figure 3-59. Parking brake lever and linkage, removal and installation.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Repair or replace worn, defective or damaged parts.


*c. Installation.* Install the steering valve lever and linkage in reverse of the instructions on figure 3-61.

**3-94. Throttle Lever and Linkage**


*a. Removal.* Remove the throttle lever and linkage as instructed on figure 3-62.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects,




A. CONTROL SHAFT AND LINKAGE




B. TRANSMISSION; CLUTCH AND GEARSHIFT LINKAGE

MEC 3895-272-12/3-60

*Figure 3-60. Gearshift and clutch levers and linkage, removal and installation.*



A. STEERING LINK VALVE END.



B. STEERING-PIVOT LEVER AND LINK.

MEC 3895-272-12/3-61

*Figure 3-61. Steering valve lever and linkage, removal and installation.*


and damage. Repair or replace worn, defective, or damaged parts.

*c. Installation.*


(1) Install the throttle lever and linkage

in reverse of the instructions on figure 3-62.

(2) Adjust the throttle linkage (para 3-58).



A. THROTTLE CONTROL



B. THROTTLE LINKAGE

MEC 3895-272-12/3-62

Figure 3-62. Throttle lever and linkage, removal and installation.

### 3-95. Sprinkler Pedals and Linkage

- a. *Removal.* Remove the sprinkler pedals and linkage as instructed on figure 3-63.
- b. *Cleaning, Inspection, and Repair.*
  - (1) Clean all parts with an approved cleaning solvent.
  - (2) Inspect all parts for wear, defects, and damage. Repair or replace worn, defective, or damaged parts.
- c. *Installation.*
  - (1) Install the sprinkler pedals and linkage in reverse of the instructions on figure 3-63.
  - (2) Adjust the sprinkler pedal linkage (para 3-18).

### 3-96. Engine Oil Pressure Gage

- a. *Removal.* Remove the engine oil pressure gage as instructed on figure 3-64.
- b. *Cleaning and Inspection.*
  - (1) Clean all parts with an approved cleaning solvent.
  - (2) Inspect all parts for defects and damage. Replace defective or damaged parts.
- c. *Installation.* Install the engine oil pressure gage in reverse of the instructions on figure 3-64.

### 3-97. Fuel Level Gage


- a. *Removal.* Remove the fuel level gage as instructed on figure 3-64.
- b. *Cleaning and Inspection.*
  - (1) Clean all parts with an approved cleaning solvent.
  - (2) Inspect all parts for defects and damage. Replace defective or damaged parts.
- c. *Installation.* Install the fuel level gage in reverse of the instructions on figure 3-64.

### 3-98. Engine Temperature Gage


- a. *Removal.* Remove the engine temperature gage as instructed on figure 3-64.
- b. *Cleaning and Inspection.*
  - (1) Clean all parts with an approved cleaning solvent.
  - (2) Inspect all parts for defects and damage. Replace defective or damaged parts.
- c. *Installation.* Install the engine temperature gage in reverse of the instructions on figure 3-64.

### 3-99. Battery Indicator Gage

- a. *Removal.* Remove the battery indicator gage as instructed on figure 3-64.



A. SPRINKLER CONTROL RODS AT VALVES.



B. SPRINKLER PEDALS AND LINKAGE.

MEC 3895-272-12-1-63

Figure 3-63. Sprinkler pedals and linkage, removal and installation.

**b. Cleaning and Inspection.**

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for damage. Replace defective or damaged parts.

**c. Installation.** Install the battery indicator gage in reverse of the instructions on figure 3-64.

### 3-100. Converter Oil Pressure Gage

**a. Removal.** Remove the converter oil pressure gage as instructed on figure 3-64.

**b. Cleaning and Inspection.**

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for defects and damage. Replace defective or damaged parts.

**c. Installation.** Install the converter oil pressure gage in reverse of the instructions on figure 3-64.

### 3-101. Converter Oil Temperature Gage

**a. Removal.** Remove the converter oil temperature gage as instructed on figure 3-64.

**b. Cleaning and Inspection.**

- (1) Clean all parts with an approved cleaning solvent.

- (2) Inspect all parts for defects and damage. Replace defective or damaged parts.

**c. Installation.** Install the converter oil temperature gage in reverse of the instructions on figure 3-64.

### 3-102. Hour Meter

**a. Removal.** Remove the hour meter as instructed on figure 3-64.

**b. Cleaning and Inspection.**

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for defects and damage. Replace defective or damaged parts.

**c. Installation.** Install the hour meter in reverse of the instructions on figure 3-64.


### 3-103. Instrument Panel Light

**a. Removal.** Remove the instrument panel light as instructed on figure 3-64.


**b. Cleaning and Inspection.**

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for defects and damage. Replace defective or damaged parts.





A. INSTRUMENT PANEL, FRONT VIEW.



B. INSTRUMENT PANEL, REAR VIEW.

MEC 3895-272-12.3-64

Figure 3-64. Instrument panel and instruments, removal and installation.

c. *Installation.* Install the instrument panel light in reverse of the instructions on figure 3-64.

### 3-104. Torque Converter Oil Pressure Sending Unit

a. *Removal.* Remove the torque converter oil pressure sending unit as instructed on figure 3-65.

b. *Cleaning, Inspection, and Repair.*

- (1) Clean the sending unit with a cloth and cleaning solvent.
- (2) Inspect the unit for damage. Check it for proper operation. Replace a defective sending unit.

c. *Installation.* Install the converter oil pressure sending unit in reverse of instructions on figure 3-65.

### 3-105. Engine Oil Pressure Sending Unit

a. *Removal.* Remove the engine oil pressure sending unit as instructed on figure 3-66.

b. *Cleaning, Inspection, and Repair.*

- (1) Clean the engine oil pressure sending unit with a cloth and approved cleaning solvent.




Figure 3-65. Torque converter oil pressure sending unit, removal and installation.




Figure 3-66. Engine oil pressure sending unit, removal and disassembly.

- (2) Inspect the unit for damage and for proper operation. Replace a defective unit.

c. *Installation.* Install the engine oil pressure sending unit in reverse of the instructions on figure 3-66.

### 3-106. Torque Converter Oil Temperature Sending Unit

a. *Removal.* Remove the torque converter oil temperature sending unit as instructed on figure 3-67.

b. *Cleaning, Inspection, and Repair.*

- (1) Clean the converter oil temperature sending unit with a cloth and approved cleaning solvent.
- (2) Inspect the unit for damage. Check for proper operation. Replace a defective unit.

c. *Installation.* Install the converter oil temperature sending unit in reverse of the instructions on figure 3-67.

### 3-107. Floodlamp Switches

a. *Removal.* Remove the floodlamp switches as instructed on figure 3-64.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.




Figure 3-67. Torque converter oil temperature sending unit, removal and installation.

- (2) Inspect all parts for defects and damage. Check switch continuity in the on position. Replace defective, damaged, or inoperative parts.
- c. *Installation.* Install floodlamp switches in reverse of the instructions on figure 3-64.

### 3-108. Ignition Switch

- a. *Removal.* Remove the ignition switch as instructed on figure 3-64.
- b. *Cleaning and Inspection.*
  - (1) Clean all parts with an approved cleaning solvent.
  - (2) Inspect all parts for defects and damage. Inspect the switch for proper operation. Replace defective, damaged, or inoperative parts.
- c. *Installation.* Install the ignition switch in reverse of the instructions on figure 3-64.

### 3-109. Trouble Light Receptacle

- a. *Removal.* Remove the trouble light receptacle as instructed on figure 3-64.
- b. *Cleaning and Inspection.*
  - (1) Clean all parts with an approved cleaning solvent.
  - (2) Inspect all parts for defects and damage. Replace defective or damaged parts.
- c. *Installation.* Install the trouble light receptacle in reverse of the instructions on figure 3-64.

## Section XIII. HYDRAULIC SYSTEM

### 3-110. Description

The hydraulic system consists of a hydraulic pump, cylinders, hydraulic filter, control valve, relief valve, hydraulic reservoir, lines, and fittings. The hydraulic cylinder is actuated by oil under pressure controlled by the control valve. Relief valve opens when the cylinder reaches the full limit of travel and the oil is by-passed to the oil reservoir.

*Note.* Prompt and firm response in the hydraulic steering system is possible only when the system is free from air. Sluggish and spongy response can be caused by air in the system. Remove by opening the line at the highest point and operating the cylinder to remove the air from the lines.

### 3-111. Steering Cylinder

- a. *Removal.* Remove the steering cylinder as instructed on figure 3-68.
- b. *Cleaning, Inspection, and Repair.*
  - (1) Clean all parts with an approved cleaning solvent.

- (2) Inspect all parts for wear, defects, and damage. Replace worn, defective, or damaged parts.

c. *Installation.* Install the steering cylinder in reverse of the instructions on figure 3-68.

### 3-112. Hydraulic Pump Drive Belt

- a. *Removal.* Remove the hydraulic pump belt as instructed on figure 3-69.
- b. *Cleaning and Inspection.*
  - (1) Clean the belt with an approved cleaning solvent.
  - (2) Inspect the belt for wear, cuts, and fraying. Replace a badly worn or damaged belt.
- c. *Installation.* Install the hydraulic pump belt in reverse of the instructions on figure 3-69.

### 3-113. Hydraulic Pump

- a. *Removal.* Remove the hydraulic pump as instructed on Figure 3-70.






Figure 3-68. Steering cylinder, removal and installation.

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the pump for damage and proper operation. Replace a damaged or inoperative pump.

*c. Installation.* Install the hydraulic pump in reverse of the instructions on figure 3-70.




Figure 3-69. Hydraulic pump belt, removal and installation.

*c. Installation.*

- (1) Install the steering control and regulating valve assembly in reverse of the instructions on figure 3-71.
- (2) Connect the control lever linkage to the valve (para 3-93).

*d. Adjustment.* Adjust the pressure regulator valve as instructed on figure 3-71.

### 3-114. Steering Control and Pressure Regulating Valve

*a. Removal.*

- (1) Disconnect the control lever linkage from the control valve (para 3-93).
- (2) Remove the steering control and regulating valve assembly as instructed on figure 3-71.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean the control valve in approved cleaning solvent.
- (2) Inspect the valve for damage, cracked housing, loose fit of plungers in housing, and other defects. Check spring for cracking, weakness, or other defects.
- (3) Inspect the plunger and ball for pitting, cracking, grooving, or other damage. Replace defective parts.


### 3-115. Hydraulic Tank, Lines, and Fittings

*a. Removal.* Remove the hydraulic tank, lines, and fittings as instructed on figure 3-72.


*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for defects and damage. Replace defective or damaged parts.


*c. Installation.* Install the hydraulic tank, lines and fittings in reverse of the instructions on figure 3-72. Refer to figure 3-73 for piping diagram.




*Figure 3-70. Hydraulic pump, removal and installation.*




*Figure 3-71. Steering control and regulating valve, removal and installation.*



A. HYDRAULIC TANK DRAIN AND LOWER CONNECTIONS




B. HYDRAULIC TANK AND LINES



C. HYDRAULIC FILTER REMOVAL.

MEC 3895-272-12/3-72

*Figure 3-72. Hydraulic tank, lines and fittings, removal and installation.*



MEC 3895-273-12/3-78

Figure 3-73. Hydraulic piping diagram.

#### Section XIV. HOUSING, PANELS, PLATFORM, SEAT ASSEMBLY, INSTRUMENT PANEL AND TOOL BOX

##### 3-116. Description

The drive roll housing covers the entire front end of the roller, and protects the drive roll assembly. The side covers, door, and brake inspection covers are secured to it. The platform upon which are located the operating controls, covers the transmission and linkages for the controls. The frame cover provides protection for the engine and hydraulic systems, and supports the instrument panel and some of the controls. A gear cover fastens to the frame on the left side of the roller, and protects the intermediate gear and pinion. Dust shield panels protect the under side of the roller at the rear end, over the steering roll assembly. The instrument panel houses all the instruments and manual switches.

##### 3-117. Seat Assembly

a. *Removal.* Remove the seat assembly as instructed on figure 3-74.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.

- (2) Inspect all parts for wear and damage. Replace worn or damaged parts.

c. *Installation.* Install the seat assembly in reverse of the instructions on figure 3-74.

##### 3-118. Drive Roll Housing Assembly

a. *Removal.* Remove the housing from the roller as instructed on figure 3-75.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Replace worn, defective, or damaged parts.

c. *Installation.* Install the housing in reverse of the instructions on figure 3-75.

##### 3-119. Panels, Covers, and Dirt Shields

a. *Removal.* Remove the panels, covers, and shields as instructed on figure 3-75.

b. *Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Repair or replace worn, defective, or damaged parts.




Figure 3-74. Seat assembly, removal and installation.

*c. Installation.* Install the panels, covers, and shields in reverse of the instructions on figure 3-75.

### 3-120. Instrument Panel

*a. Removal.* Remove the instrument panel and strip off the instruments, switches, and controls and lights as instructed on figure 3-64.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean the instrument panel in cleaning solvent.
- (2) Inspect panel for damage or corrosion.
- (3) Replace a badly damaged panel as required.

*c. Installation.* Install the controls, switches, and instruments on the instrument panel in reverse of the instructions on figure 3-64.

### 3-121. Platform

*a. Removal.*

- (1) Disconnect linkage from service brake, parking brake, and sprinkler system pedals by removing pins from yokes on linkage rods (figure 3-76).
- (2) Disconnect throttle linkage by removing nut from ball joint on throttle rod.
- (3) Remove platform (figure 3-77).

*b. Cleaning and Inspection.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Replace worn, defective or damaged parts.

*c. Installation.*

- (1) Install platform on roller frame in reverse of instructions on figure 3-77.
- (2) Install linkage for service brake, parking brake, and sprinkler system pedals in reverse of instructions on figure 3-76.


### 3-122. Tool Box

*a. Removal.* Remove capscrews (2) from bottom of tool box, and remove from roller (fig. 3-78).

*b. Cleaning and Inspection.*

- (1) Clean the tool box with an approved cleaning solvent.
- (2) Inspect for broken hinge or catch. Repair any welded joints or hardware as necessary.


*c. Installation.* Reverse instructions in *a* above.




MEC 3895-272-12/3-75

Figure 3-75. Drive roll housing, panels, covers and dirt shields, removal and installation.






A. SERVICE BRAKE LINKAGE.



B. PARKING BRAKE LINKAGE



C. SPRINKLER SYSTEM AND THROTTLE CONTROL RODS.

MEC 3895-272-12/3-76

**Figure 3-76. Brakes and sprinkler linkage, removal and installation.**






Figure 3-77. Platform, removal and installation.




Figure 3-78. Tool box, removal and installation.

## Section XV. ROLLS AND ROLL SCRAPERS

### 3-123. Description

The rolls and roll scrapers consists of the guide roll, the drive roll, and the roll scrapers. The roll scrapers are equipped with adjustable tension springs to provide the necessary scraper pressure to properly clean the rolls. The roll bearings normally do not require frequent adjustment; looseness of a roll on its shaft generally indicates a damaged bearing. Roll bearings should be checked and adjusted every 1,000 hours.

### 3-124. Guide Roll Adjustment

a. For initial adjustment after maintenance on guide rolls, axle, or bearings, tighten capscrows equal number of turns at both ends of axle (fig. 3-79). Then tighten capscrows firmly at one end of axle. If extreme torque is applied to capscrows, the roll will bind. Secure adjustment with lockwire.

b. For periodic adjustment, remove lockwire and tighten capscrows at one end as instructed in a. above. Secure adjustment with lockwire.

### 3-125. Drive Roll Adjustment

a. To service the drive roll and axle assembly, usually an adjustment and lubrication of the bearings is all that is necessary.

b. Adjustment.

- (1) Initial adjustment of drive roll bearings is done by turning adjusting screws on outside of adjusting plate clockwise to tighten the bearings, and counterclockwise to loosen the bearings (fig. 3-80).

**Caution:** EXERCISE CARE THAT THE ROLL WILL TURN FREELY AND YET WITHOUT ENDPLAY.

### 3-126. Roll Scrapers

a. *Removal.* Remove the roll scrapers as instructed on figure 3-81.




Figure 3-79. Guide roll adjustment.

- (2) Periodic check should be made for loose condition approximately every 1,000 hours of operation, and adjustment made to original position.






Figure 3-80. Drive roll adjustment.



A. GUIDE ROLL SCRAPERS



B. DRIVE ROLL SCRAPERS

MEC 3895-272-12:3-81

Figure 3-81. Roll scrapers, removal and installation.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, and damage. Repair or replace worn, defective, or damaged parts.

*c. Installation.* Install the roll scrapers in reverse of the instructions on figure 3-81.

*d. Adjustment.*

- (1) Guide roll adjustment. See figure 3-79.

*Note.* The scrapers should not be adjusted too tightly against the rolls, as excessive tension increases wear on the scraper blade.

- (2) Drive roll adjustment. See figure 3-80.

**Caution: KEEP STONES OR ANY HARD OR ABRASIVE MATERIAL FROM LODGING UNDER SCRAPERS, AS IT WILL CAUSE UNNECESSARY WEAR AND GROOVING OF THE ROLLS.**

## Section XVI. SPRINKLER SYSTEM

### 3-127. Description

The sprinkler system consists of a 130 gallon capacity tank, hose, piping, and cocoa mats. The front and rear spray bars are independently controlled by foot pedals located on the operator's platform. Water from the tank flows through piping and hose to the spray bars and cocoa mats. The cocoa mats distribute the water evenly across the rolls. This prevents bituminous materials from sticking to the rolls. The system can best be maintained by using clean, mineral-free water, and flushing the tank occasionally with an approved cleaning solution.

### 3-128. Water Tank

*a. Removal.*

- (1) Remove plug (23, fig. 3-82). Depress guide roll sprinkler pedal to drain water tank.
- (2) Remove side doors and platform (para 3-121).
- (3) Drain fuel tank and remove fuel line (para 3-57).
- (4) Disconnect adapter (11, fig. 3-82) and remove tee (22) and pipe (21).
- (5) Remove drive roll housing (water tank) as instructed in paragraph 3-118.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solution.
- (2) Inspect the tank for leaks and damage. Weld holes and cracks. Replace a badly damaged tank.

- (3) Inspect the cap and strainer for damage. Replace a damaged cap and strainer.

*c. Installation.* Install the drive roll housing (water tank) in the reverse of instructions in paragraph 3-128a. above.


### 3-129. Sprinkler System Valves, Lines, Hoses and Fittings

*a. Removal.*

- (1) Remove side doors, drive roll housing door, and upper dust shield panel (para 3-118).
- (2) Remove plug (23, fig. 3-82) and depress sprinkler pedals to drain the system.
- (3) Remove hose clamps (4) and hoses (3, 13, 29, and 36).
- (4) Remove caps (37), sprinkler pipes (18), tees (17), nipples (16 and 42), elbows (15), and slip nipples (14).
- (5) Disconnect adapter (11) and remove pipe (12).
- (6) Remove clamp (35) and tube (30).
- (7) Remove clamp (25) and disconnect adapter (11) to remove tube (24).
- (8) Remove tee (22) and pipe (21).
- (9) Remove U-bolts (38) and remove items (5, 6, 7, 8, 9, 10, 19, and 20) as a unit and then disassemble.
- (10) Remove slip nipple (2) and elbow (1).

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.



MEC 3985-272-12/3-82

Figure 3-82. Sprinkler system, exploded view.

- (2) Inspect all hoses for deterioration and damage.
- (3) Check pipe for damage, scale deposits and leaks.
- (4) Check valves for leaks and damage.
- (5) Replace defective parts.

*c. Installation.* Install the sprinkler system lines and fittings in the reverse of instructions in paragraph 3-129 a (1) through (10).

*d. Adjustment.* Adjust sprinkler system valves and linkage (para 3-18).

## Section XVII. TRANSMISSION

### 3-130. Description

The transmission assembly is located behind the engine and consists of the forward and reverse clutches, gears, and housing. The transmission is connected to the engine through the torque converter and transmits the engine torque to the drive roll.

### 3-131. Forward and Reverse Clutch Adjustment

Adjust the forward and reverse clutch as instructed in para 3-14.

### 3-132. Service Brake Adjustment

Adjust the service brake as instructed in para 3-15.

### 3-133. Transmission Levers and Linkage

*a. Removal.* Remove the transmission levers and linkage as instructed on figure 3-60.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect all parts for wear, defects, or damage. Repair or replace worn, defective, or damaged parts.

*c. Installation.* Install the transmission levers and linkage in reverse of the instructions on figure 3-60.

### 3-134. Transmission Breather

*a. Removal.* Remove the transmission breather as instructed on figure 3-4.

*b. Cleaning and Inspection.*

- (1) Clean the breather in an approved cleaning solvent.
- (2) Inspect for damage. Replace an un-serviceable filter.

*c. Installation.* Install the transmission breather in reverse of the instructions on figure 3-4.

## Section XVIII. PARKING BRAKE

### 3-135. Description

The parking brake consists of a brake band which is tightened around a drum on the drive roll by application of the parking brake lever.

### 3-136. Parking Brake

*a. Removal.* Remove the parking brake from the drive roll as instructed on figure 3-83.

*b. Cleaning, Inspection, and Repair.*

- (1) Clean all parts with an approved cleaning solvent.
- (2) Inspect the lining for wear and damage. Replace worn or damaged lining.

*c. Installation.*

- (1) Install the parking brake in reverse of the instructions on figure 3-83.
- (2) Adjust parking brake (para 3-16).






Figure 3-83. Parking brake, removal and installation.

## Section XIX. STEERING YOKE AND KINGPIN ADJUSTMENT

### 3-137. Steering Yoke and Kingpin Adjustment

*a. General.* The steering yoke assembly and kingpin assembly are located at the rear of the roller, and provide the steering mechanism. The guide rolls are attached to the steering yoke assembly which in turn is connected to the kingpin assembly. Bearings in the yoke and kingpin do not require frequent adjustment; looseness generally indicates a damaged bearing. Bearings should be checked and adjusted every 1000 hours.

#### *b. Yoke Swivel Bearing Adjustment.*


- (1) Remove six capscrews (7, fig. 3-84), washers (14), cover (8), gasket (9) from retainer (13).
- (2) Remove lockwire (10) from adjusting bolts (11). Tighten adjust-

ing bolts evenly to prevent loading bearings unevenly. Tighten bolts to obtain 20 to 24 inch-pounds drag at the swivel.

- (3) Secure adjusting bolts (11) with lockwire (10). Install gasket (9), cover (8), washers (14), and capscrews (7).

#### *c. Kingpin Adjustment.*

- (1) Remove lockwire (1) from heads of capscrews (2).
- (2) Tighten the three capscrews (2) evenly to obtain 20-24 inch-pounds drag at the kingpin. Secure the capscrews with lockwire.
- (3) Tighten nuts (4) on capscrews (6) to lock arm (15) in position.



MEC 3895-273-12/3-92

**Figure 3-84. Steering yoke bearing and kingpin adjustment.**



## APPENDIX A

### REFERENCES

---

#### A-1. Fire Protection

TB 5-4200-200-10

Hand Portable Fire Extinguisher for Army Use.

#### A-2. Lubrication

C9100-IL

LO 5-3895-272-12

Petroleum, Petroleum-Base Products, and Related Materials.  
Lubrication Order.

#### A-3. Painting

TM 9-213

Painting Instructions for Field

#### A-4. Maintenance

TM 9-6140-200-15

TM 38-750

TB ENG 347 (Used  
only when pub-  
lished)

TM 5-3895-272-20P

Storage Batteries, Lead-Acid Type.  
Army Equipment Record Procedures.  
Winterization Techniques for Engineer Equipment.

Organizational Maintenance Repair Parts and Special Tools List



## APPENDIX B

### BASIC ISSUE ITEMS LIST, MAINTENANCE AND OPERATING SUPPLIES

---

#### Section I. INTRODUCTION

##### B-1. General

Section II lists the accessories, tools, and publications required for maintenance and operation by the operator which are initially issued with, or authorized for use with the (5 to 8 ton tandem roller). Section III lists the maintenance and operating supplies required for initial operation.

##### B-2. Explanation of Columns Contained in Section II

a. *Source Codes.* The information provided in each column is as follows:

- (1) *Materiel.* This column is left blank. For identification of agencies assigned supply responsibility for parts, refer to appropriate Federal and Department of Army supply catalogs.
- (2) *Source.* The selection status and source of supply for each part are indicated by one of the following code symbols:
  - (a) P—applied to high-mortality repair parts which are stocked in or supplied from the army supply system, and authorized for use at indicated maintenance categories.
  - (b) P1—applied to repair parts which are low-mortality parts, stocked in or supplied from supply service depots, and authorized for installation at indicated maintenance level.
  - (c) M—applied to repair parts which are not procured or stocked but

are to be manufactured at indicated maintenance level.

- (d) X2—applied to repair parts which are not stocked. The indicated maintenance level requiring such parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.
- (3) *Maintenance.* The lowest maintenance level authorized to use, stock, install, or manufacture the part is indicated by the following code symbol.
 

O—Organizational Maintenance
- (4) *Recoverability.* Repair parts and/or tool and equipment items that are recoverable are indicated by one of the following code symbols.
  - (a) R—applied to repair parts and assemblies which are economically repairable at direct and general support maintenance activities and normally are furnished by supply on exchange basis.
  - (b) T—applied to high-dollar value recoverable repair parts which are subject to special handling and are issued on an exchange basis. Such repair parts normally are repaired or overhauled at depot maintenance facilities.

- (c) U—applied to repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, high-dollar value reusable casings, castings, and the like.

*Note.* When no code is shown in the recoverability column the part is considered expendable.

*b. Federal Stock Number.* When a Federal stock number is available for a part, it will be shown in this column, and will be used for requisitioning purposes.

*c. Description.*

- (1) The item name and a brief description of the part are shown.
- (2) A five-digit Federal supply code for manufacturers and/or other supply services is shown in parentheses followed by the manufacturer's part number. This number shall be used for requisitioning purposes when no Federal stock number is indicated in the Federal stock number column.

*Example:* (08645) 86453

*d. Unit of Issue.* If no abbreviation is shown in this column, the unit of issue is "each".

*e. Quantity Authorized.* This column lists the quantities of repair parts, accessories, tools, or publications authorized for issue to the equipment operator or crew as required.

*f. Quantity Issued with Equipment.* This column lists the quantities of repair parts, accessories, tools, or publications that are initially issued with each item of equipment. Those indicated by an asterisk are to be requisitioned through normal supply channels as required.

*g. Illustrations.* This column is subdivided into two columns which provide the following information:

- (1) *Figure number.* Provides the identifying number of the illustration.
- (2) *Item number.* Provides the reference number for the parts shown in the illustration.

### B-3. Explanation of Columns Contained in Section III

*a. Item.* This column contains numerical sequenced item numbers, assigned to each component application, to facilitate reference.

*b. Component Application.* This column identifies the component application of each maintenance or operating supply item.

*c. Source of Supply.* This column is left blank. For identification of agencies assigned supply responsibility for parts, refer to appropriate Federal and Department of Army Supply Catalogs.

*d. Federal Stock Number.* The Federal stock number will be shown in this column and will be used for requisitioning purposes.

*e. Description.* The item and a brief description are shown.

*f. Quantity Required for Initial Operation.* This column lists the quantity of each maintenance or operating supply item required for initial operation of the equipment.

*g. Quantity Required for Eight Hours Operation.* Quantities listed represent the estimated requirements for an average eight hours of operation.

*h. Notes.* This column contains informative notes keyed to data appearing in the preceding column.

## Section II. BASIC ISSUE ITEMS LIST

Material	Source codes			Federal stock number	Description	Unit of issue	Quantity authorized	Quantity issued with equipment	Illustration	
	Source	Maintenance	Recoverability						Figure	Item
09	P	O		6140-057-2554	GROUP 06 ELECTRICAL SYSTEM 0612 BATTERIES					
03	P1	O		6810-249-9364	BATTERIES ELECTROLITE	GAL	2 4	2 4		
					GROUP 31—BASIC ISSUE ITEMS, MANUFACTURER INSTALLED					
					3100 BASIC ISSUE ITEMS, MANUFACTURER OR DEPOT INSTALLED					
	P	O		7520-559-9618	CASE: Operations & Maintenance Publications, Cotton-duck, water repellent & mildew resistant. MIL-B-11743B (GE).		1	1		
12					LO 5-3895-272-12 Lubrication Order.		1	1		
12					TM 5-3895-272-12 Operator & Organizational Maintenance Manual.		2	2		
12					TM 5-3895-272-20P Organizational Maintenance Repair Parts.	1	2	2		
12					TM 5-3895-272-35 Direct and General Support and Depot Maintenance Manual.		2			
					TM 5-3895-272-35P Direct and General Support and Depot Maintenance Repair Parts.		2			
					GROUP 32—BASIC ISSUE ITEMS TROOP INSTALLED					
					3200 BASIC ISSUE ITEMS TROOP INSTALLED OR AUTHORIZED					
10	P	O		4930-360-2801	GREASE, GUN: hand, lever operated, 16 ounce capacity extension 7 in. lg, and hydraulic coupler MIL-G-3859.		1	*		
10	P	O		5120-242-3971	HAMMER, HAND: 1 LB. Machinists		1	*		
10	P	O		4930-168-3252	OILER, HAND: force fed by internal pump 8 ounce capacity.		1	*		
10	P	O		5120-233-3796	PLIERS, SLIP JOINT: straight nose combination w/cutter, 6 in. long.		1	*		
10	P	O		5120-234-8910	SCREWDRIVER, FLAT TIP: plastic handle 5/16 in., tip, 6 in. long.		1	*		
10	P	O		5120-264-3796	WRENCH, OPEN END, ADJUSTABLE: 0" to 1 5/16 in. jaw opening, 12 in. long.		1			
					GROUP 76—FIRE FIGHTING EQUIPMENT					
					7603 FIRE EXTINGUISHERS					
	P	O		4210-893-1092	EXTINGUISHERS, FIRE: dry type, w/bracket, Wall (GE) 2 1/2 lb. capacity.					

## Section III. MAINTENANCE AND OPERATING SUPPLIES

(1) Item	(2) Component application	(3) Federal stock number	(4) Description	(5) Quantity required f/initial operation	(6) Quantity required f/8 hrs operation	(7) Notes
1.	0101 CRANKCASE (1)	9150-265-9435(2) 9150-265-9428(2) 9150-242-7603(2)	OIL, LUBRICATING 5 gal pails as follows: OE-30 OE-10 OES	5 qt.	(3) (3) (3)	(1) Includes quantity of oil to fill engine oil system as follows: 5 qt.—crankcase 1 qt.—oil filter
2.	0203 TORQUE CONVERTER		OIL, LUBRICATING: (4) OE-10 OES	7 1/2 qt.	(3) (3)	(2) See C9100-IL for ad- ditional data and requi- sitioning procedure.
3.	0304 AIR CLEANER		OIL, LUBRICATING: (4) OE-30 OE-10 OES	1 qt.	(3) (3) (3)	(3) See current LO for grade application and replenishment intervals.
4.	0306 TAN, FUEL	9130-160-1818 9130-160-1830	FUEL, GASOLINE: bulk as follows: automotive, combat 91A automotive, combat 91C	25.5 (5)	40 gal. (6)	(4) Use oil as prescribed in item 1.
5.	0501 RADIATOR	6850-224-8730	WATER: ANTIFREEZE: 5 gal. cans as follows: antifreeze ethylene glycol	16 qt.		(5) Tank capacity
6.	0800 TRANSMISSION	6850-174-1806	ANTIFREEZE: 55 gal. drums as follows: Antifreeze: compound, artic	16 qt.		(6) Average fuel consump- tion is 5.0 gal. per hour of continuous operation.
7.	1103 FINAL DRIVE GEARS	9150-577-5844 9150-257-5440 9150-234-5197(2) 9150-234-5199(2)	LUBRICATING OIL, GEAR 5 gal. cans as follows: GO-90 GOS OIL, LUBRICATING, GEAR 5-lb. can as fol- lows: CW-11A CW-11B	9 qt. (5)  5 lb 5 lb	(3) (3) (3) (3)	

(1) Item	(2) Component application	(3) Federal stock number	(4) Description	(5) Quantity required f/initial operation	(6) Quantity required f/8 hrs operation	(7) Notes
8.	1413 HYDRAULIC SYSTEM		OIL, LUBRICATING: (1) OE-10 OES WATER	26 qt. (5) 130 gal.	(3)	
9.	7471 SPRINKLER SUPPLY TANK		GREASE, AUTOMOTIVE AND ARTILLERY: (3) 5-lb. can as follows: GAA	5 lb	1 lb	
10.	GREASE POINTS	9150-190-0905 (2)				





## APPENDIX C

### MAINTENANCE ALLOCATION CHART

---

#### Section I. INTRODUCTION

##### 1. General

a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance levels.

b. Section II designates overall responsibility for the performance of maintenance operations on the identified end item or component. The implementation of the maintenance tasks upon the end item or component will be consistent with the assigned maintenance operations.

c. Section III lists the special tools and test equipment required for each maintenance operation as referenced from Section II.

d. Section IV contains supplemental instructions, explanatory notes and/or illustrations required for a particular maintenance function.

##### 2. Explanation of Columns in Section II

a. *Functional Group Number.* The functional group is a numerical group set up on a functional basis. The applicable functional grouping indexes (obtained from TB 750-93-1, Functional Grouping Codes) are listed on the Maintenance Assignment in the appropriate numerical sequence. These indexes are normally set up in accordance with their function and proximity to each other.

b. *Component Assembly Nomenclature.* This column contains a brief description of the components of each functional group.

c. *Maintenance Functions and Maintenance Categories.* This column lists the various maintenance functions (A through K) and indicates the lowest maintenance category authorized to perform these operations. The symbol designates

nations for the various maintenance categories are as follows:

- C—Operator or crew
- O—Organizational maintenance
- F—Direct support maintenance
- H—General support maintenance
- D—Depot maintenance

The maintenance functions are defined as follows:

- A—INSPECT: Verify serviceability and detect incipient electrical or mechanical failure by close visual examination.
- B—TEST: Verify serviceability and detect incipient electrical or mechanical failure by measuring the mechanical or electrical characteristics of the item and comparing those characteristics with authorized standards. Tests will be made commensurate with test procedures and with calibrated tools and/or test equipment referenced in the Maintenance Assignment.
- C—SERVICE: Operations required periodically to keep the item in proper operating condition, i.e., to clean, preserve, drain, paint, and replenish fuel, lubricants, hydraulic, and deicing fluids or compressed air supplies
- D—AI  
ve
- E.

- F—CALIBRATE: Determine, check, or rectify the graduation of an instrument, weapon, or weapons system or components of a weapons system.
- G—INSTALL: Remove and install the same item for service or when required for the performance of other maintenance operations.
- H—REPLACE: Substitute serviceable components, assemblies and subassemblies for unserviceable counterparts.
- I—REPAIR: Restore to a serviceable condition by replacing unserviceable parts or by any other action required using available tools, equipment and skills, including welding, grinding, riveting, straightening, adjusting and facing.
- J—OVERHAUL: Restore an item to a completely serviceable condition (as prescribed by serviceability standards developed and published by the commodity commands) by employing techniques of "Inspect and Repair Only as Necessary" (IROAN). Maximum use of diagnostic and test equipment is combined with minimum disassembly during overhaul. "Overhaul" may be assigned to any level of maintenance except organizational, provided the time, tools, equipment, repair parts authorization, and technical skills are available at that level. Normally, overhaul as applied to end items, is limited to depot maintenance level.
- K—REBUILD: Restore to a condition comparable to new by disassembling to determine the condition of each component part and reassembling using serviceable, rebuilt, or new assemblies, subassemblies, and parts.

*d. Notes Reference.* This column, subdivided into columns L and M, is provided for referencing the Special Tool and Test Equipment Requirements (Sec. III) and Remarks (Sec. IV) that may be associated with maintenance functions (Sec. II).

### 3. Explanation of Columns in Section III

*a. Reference Code.* This column consists of a number and a letter separated by a dash. The number references the T and TE requirements column on the Maintenance Assignment. The letter represents the specific maintenance function the item is to be used with. The letter is representative of columns A through K on the Maintenance Assignment.

*b. Maintenance Category.* This column shows the lowest level of maintenance authorized to use the special tool or test equipment.

*c. Nomenclature.* This column lists the name or identification of the tool or test equipment.

*d. Tool Number.* This column lists the manufacturer's code and part number, or Federal stock number of tools and test equipment.

### 4. Explanation of Columns in Section IV

*a. Reference Code.* This column consists of two letters separated by a dash, both of which are references to Section II. The first letter references column M and the second letter references a maintenance operation, columns A through K.

*b. Remarks.* This column lists information pertinent to the maintenance operation being performed, as indicated on the Maintenance Assignment Section II.

## Section II. MAINTENANCE ASSIGNMENT

Functional group number	Component assembly nomenclature	Maintenance functions												Note reference	
		A	B	C	D	E	F	G	H	I	J	K	L	M	
		INSPECT	TEST	SERVICE	ADJUST	ALIGN	CALIBRATE	INSTALL	REPLACE	REPAIR	OVERHAUL	REBUILD	Tools and Equipment	Remarks	
01	ENGINE														
0100	ENGINE ASSEMBLY	C	O	C					F	O	D	D	--	A	
0101	CRANKCASE, BLOCK, CYLINDER HEAD														
	Block, cylinder	--	--	--	--	--	--	--	H	H					
	Head, cylinder	--	--	--	--	--	--	--	O						
0102	CRANKSHAFT								H						
	Bearings	--	--	--	--	--	--	--	H						
	Pulley	--	--	--	--	--	--	--	O						
0103	FLYWHEEL ASSEMBLY								H	H					
	Housing	--	--	--	--	--	--	--	H	O					
	Plates, gaskets & cover	--	--	--	--	--	--	--	O	--	--	--	--	B	
0104	PISTONS, CONNECTING RODS														
	Pistons, rings, pins, bushings	--	--	--	--	--	--	--	H						
	Rods, connecting	--	--	--	--	--	--	--	H	H					
	Bearings	--	--	--	--	--	--	--	H						
0105	VALVES, CAMSHAFT AND TIMING SYSTEM														
	Valves	--	--	--	--	--	--	--	F	F					
	Springs, guides & locks	--	--	--	--	--	--	--	F	F					
	Seats, insert	--	--	--	--	--	--	--	F	F					
	ROCKER ARMS, TAPPETS														
	Tappets	--	--	--	O	--	--	--	F	O					
	Covers & gaskets	--	--	--	--	--	--	--	O	H					
	CAMSHAFT														
	Bearings	--	--	--	--	--	--	--	H	H					
	TIMING GEARS														
	Covers & gaskets	--	--	--	--	--	--	--	H	H					
0106	ENGINE LUBRICATION SYSTEM														
	Pump, oil	--	--	--	--	--	--	--	F	F					
	Filter, oil	--	--	C	--	--	--	--	O	O					
	Fittings	--	--	--	--	--	--	--	O	O					
	Valve, relief	--	--	--	O	--	--	--	O	O					
	Cap, filler; gage, level	--	--	--	--	--	--	--	O	O					
	Lines	--	--	--	--	--	--	--	F	O					
	Pan, oil	--	--	--	--	--	--	--	O	O					
0108	MANIFOLDS														
03	FUEL SYSTEM														
0301	CARBURETOR														
	Carburetor	--	--	O	C	--	--	--	O	F					
	Gasket, bowl	--	--	--	--	--	--	--	O						
0302	FUEL PUMP														
0304	AIR CLEANER			C	--	--	--	--	O						
0306	TANK, LINES, FITTINGS, FUEL														
	Tank	--	--	C	--	--	--	--	O	F					
	Lines	--	--	--	--	--	--	--	O	O					

Functional group number	Component assembly nomenclature	Maintenance functions											Note reference	
		A	B	C	D	E	F	G	H	I	J	K	L	M
		INSPECT	TEST	SERVICE	ADJUST	ALIGN	CALIBRATE	INSTALL	REPLACE	REPAIR	OVERHAUL	REBUILD	Tools and Equipment	Remarks
0308	Fitting-----	--	--	--	--	--	--	O						
	Cap-----	--	--	--	--	--	--	O						
	ENGINE SPEED GOVERNOR-----	--	--	--	O	--	--	O	F					
	Linkage-----	--	--	--	--	--	--	O						
0309	Governor controls-----	--	--	--	--	--	--	O						
	FUEL FILTER-----	--	--	C	--	--	--	O	O					
0312	ACCELERATOR, THROTTLE OR CHOKE CONTROLS-----	--	--	--	--	--	--	O						
04	Control, throttle, & choke-----	--	--	--	--	--	--	O						
	EXHAUST SYSTEM-----	--	--	--	--	--	--	O						
0401	MUFFLER AND PIPES-----	--	--	--	--	--	--	O						
05	COOLING SYSTEM-----	--	--	--	--	--	--	O						
0501	RADIATOR-----	C	--	C	--	--	--	O	F	--	--	--	C	
	Cap-----	--	--	--	--	--	--	C						
0503	THERMOSTAT, HOUSING, AND GASKET-----	--	--	--	--	--	--	O						
	Thermostat-----	--	O	--	--	--	--	O						
	Housing, thermostat; hoses; clamps-----	--	--	--	--	--	--	O						
0504	WATER PUMP-----	--	--	--	--	--	--	O						
	Packing-----	--	--	--	O	--	--	O						
0505	FAN ASSEMBLY-----	--	--	--	--	--	--	O	O					
	Blade, fan; guard-----	--	--	--	--	--	--	O						
	Belt, fan-----	--	--	--	C	--	--	O						
06	ELECTRICAL SYSTEM (ENGINE & VEHICULAR)-----	--	--	--	--	--	--	O						
0601	GENERATOR-----	--	O	--	--	--	--	O	F					
	Brushes-----	--	--	--	--	--	--	O						
0602	GENERATOR REGULATOR (VOLT-AGE).-----	--	O	--	O	--	--	O						
0603	STARTING MOTOR-----	--	O	O	--	--	--	O	F					
	Solenoid-----	--	--	--	--	--	--	O						
0605	IGNITION COMPONENTS-----	--	--	--	--	--	--	O						
	Magneto-----	--	--	O	O	--	--	O	F					
	Spark plugs-----	--	O	O	O	--	--	O						
0606	Points; condenser; cables-----	--	--	--	--	--	--	O						
	ENGINE SAFETY CONTROL-----	--	--	--	--	--	--	O	F					
0607	Overspeed governor-----	--	--	--	--	--	--	O						
	INSTRUMENT OR ENGINE CONTROL PANEL-----	--	--	--	--	--	--	O						
	Panel-----	--	--	--	--	--	--	O	O					
	Switch-----	--	--	--	--	--	--	O						
	Gages, electrical-----	--	--	--	--	--	--	O						
	Wiring-----	--	--	--	--	--	--	O						
0609	Lamps-----	--	--	--	--	--	--	C						
	LIGHTS: RINGS: GASKETS: SEAL-BEAM-----	--	--	--	--	--	--	O						
0610	SENDING UNITS-----	--	--	--	--	--	--	O						

Functional group number	Component assembly nomenclature	Maintenance functions											Note reference	
		A	B	C	D	E	F	G	H	I	J	K	L	M
		INSPECT	TEST	SERVICE	ADJUST	ALINE	CALIBRATE	INSTALL	REPLACE	REPAIR	OVERHAUL	REBUILD	Tools and Equipment	Remarks
0612	BATTERIES													
	Batteries.....	--	O	C	--	--	--	--	O					
	Cables, battery.....	--	--	--	--	--	--	--	O	O				
	Box, battery.....	--	--	--	--	--	--	--	O					
0613	CHASSIS WIRING HARNESS													
	Wiring Harness.....	--	--	--	--	--	--	--	--	O				
07	TRANSMISSION													
0700	TRANSMISSION ASSEMBLY (Main and/or Secondary)													
	TRANSMISSION CASE.....	C	--	C	--	--	--	--	H					
0701	TRANSMISSION SHAFTS													
	Shafts; gears; bearing.....	--	--	--	--	--	--	--	H					
0703	TRANSMISSION CLUTCH AND CLUTCH CONTROLS													
	Clutches.....	--	--	--	C	--	--	--	--	F				
	Controls.....	--	--	C	--	--	--	--	O	--	--	--	--	D
0704	TRANSMISSION TOP COVER ASSEMBLY													
	Cover, shifter.....	--	--	--	--	--	--	--	F					
	Rods and lever, control.....	--	--	--	--	--	--	--	O					
0707	TRANSMISSION BRAKE													
	Brake, transmission.....	--	--	--	O	--	--	--	F	F				
	Rods, pedal; levers.....	--	--	--	--	--	--	--	O					
0708	TORQUE CONVERTER													
	.....	--	--	C	--	--	--	--	H	H	H			
0721	PUMP													
	Oil distribution.....	--	--	--	--	--	--	--	--	H				
	Lines.....	--	--	--	--	--	--	--	O	F				
	Fittings.....	--	--	--	--	--	--	--	O					
11	REAR AXLE													
1103	FINAL DRIVE													
	Intermediate drive assembly.....	--	--	C	--	--	--	--	F	F				
	Pinion shaft assembly.....	--	--	--	--	--	--	--	F					
	Universal joint.....	--	--	--	--	--	--	--	F					
	Bearings; seals; axle.....	--	--	--	--	--	--	--	F					
12	BRAKES													
1201	HAND BRAKES													
	Brakes, hand.....	--	--	--	C	--	--	--	O	F				
	Lever.....	--	--	--	--	--	--	--	O					
	Linkage.....	--	--	--	--	--	--	--	F					
14	STEERING													
1401	STEERING ASSEMBLY													
	Steering lever and linkage.....	--	--	--	--	--	--	--	O					
1405	STEERING YOKES													
	Yoke; kingpin; bearings.....	--	--	C	--	--	--	--	--	--	--	--	--	
1410	PUMP AND PUMP DRIVE													
	Hydraulic pump.....	--	--	--	--	--	--	--	--	--	--	--	--	
	Pump drive belt.....	--	--	--	--	--	--	--	--	--	--	--	--	
	Pulley, bracket.....	--	--	--	--	--	--	--	--	--	--	--	--	



Functional group number	Component assembly nomenclature	Maintenance functions											Note reference	
		A	B	C	D	E	F	G	H	I	J	K	L	M
		INSPECT	TEST	SERVICE	ADJUST	ALIGN	CALIBRATE	INSTALL	REPLACE	REPAIR	OVERHAUL	REBUILD	Tools and Equipment	Remarks
1411	HOSES, LINES, FITTINGS													
	Hose, lines-----	--	--	--	--	--	--	--	O	F				
	Fittings-----	--	--	--	--	--	--	--	O					
1412	HYDRAULIC CYLINDER													
	Cylinder, steering-----	--	--	--	--	--	--	--	O	F				
1413	TANKS, RESERVOIRS													
	Hydraulic oil tank-----	--	--	C	--	--	--	--	O					
	Cap-----	--	--	--	--	--	--	--	C					
1414	STEERING SYSTEM VALVES													
	Valve, control-----	--	--	--	O	--	--	--	O					
	Pressure regulator-----	--	--	--	O	--	--	--	O					
15	FRAME													
1501	FRAME ASSEMBLY													
	Frame-----	--	--	--	--	--	--	--	H	F				
	Handrail-----	--	--	--	--	--	--	--	O					
18	BODY CAB, HOOD AND HULL													
1801	DRIVE ROLL HOUSING ASSEMBLY-----	--	--	--	--	--	--	--	O	O				
1806	SEAT-----	--	--	--	--	--	--	--	O					
1808	TOOL BOX-----	--	--	--	--	--	--	--	O					
1808	PLATFORM-----	--	--	--	--	--	--	--	O	--	--	--	--	E
22	MISCELLANEOUS ITEMS													
2210	DATA PLATES AND INSTRUCTION													
	HOLDERS													
	Plates, data-----	--	--	--	--	--	--	--	F					
	Plates, instruction-----	--	--	--	--	--	--	--	O					
31	BASIC ISSUE ITEMS, MANUFACTURER													
	INSTALLED													
3100	BASIC ISSUE ITEMS, MANU-													
	FACTURER OR DEPOT INSTALLED													
	Publications, case-----	--	--	--	--	--	--	--	C					
	Light, trouble-----	--	--	--	--	--	--	--	C					
	Case, rifle-----	--	--	--	--	--	--	--	C					
	Binder, log book-----	--	--	--	--	--	--	--	C					
32	BASIC ISSUE ITEMS, TROOP													
	INSTALLED													
3200	BASIC ISSUE ITEMS TROOP													
	INSTALLED OR AUTHORIZED													
	Tools, common-----	--	--	--	--	--	--	--	C					
47														
4702	GAGES													
	Gages-----	--	--	--	--	--	--	--	C					
74	CRANES SHOVELS AND EARTH													
	MOVING EQUIPMENT COMPONENTS													
7466	STEERING ROLLS-----	--	--	C	--	--	--	--	F	F				
7468	DRIVE ROLLS-----	--	--	C	--	--	--	--	F	F				
7470	ROLL SCRAPERS													
	Shaft, spring, blade-----	--	--	--	--	--	--	--	O	O				
	Bracket assembly, scraper-----	--	--	--	--	--	--	--	O					

Functional group number	Component assembly nomenclature	Maintenance functions											Note reference	
		A	B	C	D	E	F	G	H	I	J	K	L	M
		INSPECT	TEST	SERVICE	ADJUST	ALIGN	CALIBRATE	INSTALL	REPLACE	REPAIR	OVERHAUL	REBUILD	Tools and Equipment	Remarks
7471	SPRINKLER SYSTEM													
	Tank	C	--	C	--	--	--	--	O	O				
	Pipes; fittings; valves	--	--	--	--	--	--	--	O	O				
	Mat assembly	--	--	--	--	--	--	--	O					
76	FIRE FIGHTING EQUIPMENT													
7603	FIRE EXTINGUISHER	--	--	--	--	--	--	--	C	C				
	Extinguisher, fire	--	--	C	--	--	--	--	C	C				

### Section III. SPECIAL TOOL AND SPECIAL TEST EQUIPMENT REQUIREMENTS

Reference code	Maintenance level	Nomenclature	Tool number
		No Special Tools Required	

### Section IV. REMARKS

Reference code	Remarks
A-B	Test of engine includes operation and compression
B-I	Replace inspection plate gasket hardware
C-I	Locate leaks and repair using solder
D-H	Replace any bent rods; badly worn or broken ball joints
E-H	Repair or replace bent or broken tool box lid



## INDEX

	Paragraph	Page
Adjustment:		
Belts		
Fan	3-13	3-11
Generator	3-13	3-11
Hydraulic pump	3-17	3-12
Carburetor	3-9	3-11
Clutches	3-14	3-11
Governor	3-58	3-21
Magneto	3-65	3-26
Parking brake	3-16	3-11
Pressure regulator	3-114	3-53
Rolls		
Drive	3-125	3-60
Guide	3-124	3-60
Sprinkler system	3-18	3-13
Steering yoke and kingpin	3-137	3-65
Service brake	3-15	3-11
Valves	3-84	3-40
Air cleaner	3-53	3-19
Basic tools and equipment	3-2	3-1
Batteries	3-60	3-24
Battery cables	3-60	3-24
Battery frame assembly	3-61	3-24
Battery indicator gage	3-99	3-48
Belt, fan	3-76	3-36
Belt, hydraulic pump drive	3-112	3-52
Bituminous—concrete & sheet asphalt pavement operation on	2-13	2-9
Bituminous—macadam pavement, operation on	2-12	2-8
Brake, foot, pedal and linkage	3-89	3-44
Brake, parking	3-136	3-64
Brake, parking, lever and linkage	3-90	3-45
Breather, transmission	3-134	3-64
Cables, battery	3-60	3-24
Cables, spark plug	3-66	3-27
Carburetor	3-55	3-20
Cleaner, air	3-53	3-19
Clutch lever & linkage, forward & reverse	3-92	3-45
Components packed in separate cartons, installation of		2-5
Controls and instruments, general		
Controls and instruments, description		
Battery indicator gage		
Converter oil pressure gage		
Converter oil temperature gage		
Engine oil pressure gage		
Engine oil pressure sending unit		
Engine temperature gage		
Floodlamp switches		
Forward and reverse clutch lever and linkage		

	Paragraph	Page
Fuel level gage -----	3-97	3-48
Gearshift lever and linkage -----	3-91	3-45
Hour meter -----	3-102	3-49
Ignition switch -----	3-108	3-52
Instrument panel light -----	3-103	3-49
Parking brake lever and linkage -----	3-90	3-45
Sprinkler pedal and linkage -----	3-95	3-48
Steering valve lever and linkage -----	3-93	3-45
Throttle lever and linkage -----	3-94	3-46
Torque converter oil pressure sending unit -----	3-104	3-51
Torque converter oil temperature sending unit -----	3-106	3-51
Trouble light receptacle -----	3-109	3-52
Cooling system, engine, description -----	3-74	3-35
Fan assembly -----	3-77	3-37
Fan belt -----	3-76	3-36
Radiator -----	3-75	3-35
Thermostat and thermostat housing -----	3-79	3-38
Water pump -----	3-78	3-37
Water temperature sending unit -----	3-80	3-38
Crankshaft pulley -----	3-87	3-40
Cylinder head -----	3-82	3-39
Covers, engine compartment -----	3-119	3-56
Cylinder, steering -----	3-111	3-52
Daily preventive services -----	3-6	3-6
Description and tabulated data -----	1-3	1-1
Differences in models -----	1-5	1-5
Dusty or sandy areas, operation in -----	2-17	2-10
Drive roll adjustment -----	3-125	3-60
Electrical system, description -----	3-59	3-24
Batteries and battery cables -----	3-60	3-24
Battery frame assembly -----	3-61	3-24
Circuit breaker -----	3-69	3-30
Floodlamps -----	3-68	3-27
Generator -----	3-62	3-25
Magneto -----	3-65	3-26
Overspeed governor -----	3-67	3-27
Regulator, generator -----	3-63	3-25
Spark plugs and cables -----	3-66	3-27
Starter and solenoid -----	3-64	3-26
Wiring and wiring harness -----	3-70	3-30
Engine, description -----	3-81	3-39
Cylinder head -----	3-82	3-39
Exhaust pipe -----	3-86	3-40
Manifold assembly -----	3-83	3-39
Muffler -----	3-85	3-40
Valves -----	3-84	3-40
Engine fuel system, description -----	3-52	3-19
Air cleaner -----	3-53	3-19
Carburetor -----	3-55	3-20
Engine speed governor -----	3-58	3-21
Fuel level sending unit -----	3-56	3-20
Fuel pump -----	3-54	3-19
Fuel tank -----	3-57	3-20
Engine compartment cover plates -----	3-119	3-56
Engine oil pressure gage -----	3-96	3-48
Engine oil pressure sending unit -----	3-105	3-51
Engine starting -----	2-9	2-6
Engine stopping -----	2-10	2-6

	Paragraph	Page
Engine temperature gage -----	3-98	3-48
Extinguisher, fire -----	2-20	2-11
Extreme cold, operation in -----	2-15	2-9
Extreme heat, operation in -----	2-16	2-10
Fan assembly -----	3-77	3-37
Fan belt -----	3-76	3-36
Filter, oil -----	3-72	3-32
Fire extinguisher -----	2-20	2-11
Floodlamps -----	3-68	3-27
Floodlamp switches -----	3-107	3-51
Footbrake, pedal and linkage -----	3-89	3-44
Forward and Reverse Clutch Adjustment -----	3-131	3-64
Fuel level gage -----	3-97	3-48
Fuel level sending unit -----	3-56	3-20
Fuel pump -----	3-54	3-19
Fuel tank -----	3-57	3-20
Gage, battery indicator -----	3-99	3-48
Gage, converter oil pressure -----	3-100	3-49
Gage, converter oil temperature -----	3-101	3-49
Gage, engine temperature -----	3-98	3-48
Gage, fuel level -----	3-97	3-48
Gage, oil pressure, engine -----	3-96	3-48
Gearshift, lever and linkage -----	3-91	3-45
Generator -----	3-62	3-25
Generator regulator -----	3-63	3-25
Governor, engine speed -----	3-58	3-21
Governor, overspeed -----	3-67	3-27
Guide roll adjustment -----	3-124	3-60
Handling on paving jobs -----	2-14	2-9
Harness, wiring -----	3-70	3-30
High altitude, operation in -----	2-19	2-10
Hourmeter -----	3-102	3-49
Hydraulic system, description -----	3-110	3-52
Hydraulic pump -----	3-113	3-52
Hydraulic pump drive belt -----	3-112	3-52
Hydraulic tank, lines and fittings -----	3-115	3-53
Steering control and pressure regulating valve -----	3-114	3-53
Steering cylinder -----	3-111	3-52
Identification and tabulated data -----	1-4	1-2
Ignition switch -----	3-108	3-52
Indicator gage, battery -----	3-99	3-48
Inspecting and servicing equipment -----	2-3	2-1
Installation of components packed in separate cartons -----	2-4	2-5
Instruments (see controls and instruments) -----	3-120	3-57
Instrument panel -----	3-103	3-49
Instrument panel light -----	3-49	3-19
Interference suppression components -----	3-137	3-65
Kingpin, adjustment -----	3-68	3-27
Lamp, flood -----	3-92	3-45
Lever and linkage, clutch -----	3-91	3-45
Lever and linkage, gearshift -----	3-93	3-45
Lever and linkage, steering valve -----	3-94	3-46
Lever and linkage, throttle -----	3-115	3-53
Lines and fittings, hydraulic tank -----	3-4	3-1
Lubrication information, detailed -----		

**TM 5-3895-272-12**

	Paragraph	Page
Lubrication information, general .....	3-3	3-1
Lubrication system, description .....	3-71	3-32
Oil filter, lines and fittings .....	3-72	3-32
Oil pressure regulator valve, engine .....	3-73	3-33
Magneto .....	3-65	3-26
Maintenance services, preventive		
Daily .....	3-6	3-6
General .....	3-5	3-6
Quarterly .....	3-7	3-6
Manifold assembly .....	3-83	3-39
Meter, hour .....	3-102	3-49
Movement to new worksite .....	2-5	2-5
Muffler .....	3-85	3-40
Normal conditions, operation under .....	2-11	2-6
Nut and bolt torque data		
Oil filter .....	3-72	3-32
Oil pressure gage, engine .....	3-96	3-48
Oil pressure gage, converter .....	3-100	3-49
Oil pressure regulator valve, engine .....	3-73	3-33
Oil pressure sending unit, engine .....	3-105	3-51
Oil pressure sending unit, torque converter .....	3-104	3-51
Oil temperature sending unit, torque converter .....	3-106	3-51
Operation:		
Handling on paving jobs .....	2-14	2-9
In dusty or sandy areas .....	2-17	2-10
In extreme cold .....	2-15	2-9
In extreme heat .....	2-16	2-10
In high altitude .....	2-19	2-10
In salt water or high humidity areas .....	2-18	2-10
On Bituminous—concrete and sheet asphalt pavement .....	2-13	2-9
On Bituminous—Macadam pavement .....	2-12	2-8
Under normal conditions .....	2-11	2-6
Operation of equipment		
Starting the engine .....	2-9	2-6
Stopping the engine .....	2-10	2-6
Operator's maintenance		
Ballast rolls service .....	3-21	3-13
Carburetor .....	3-9	3-11
Clutches, forward and reverse, adjustment .....	3-14	3-11
Cooling system service .....	3-12	3-11
Fan belt .....	3-13	3-11
Fuel pump .....	3-10	3-11
Fuel tank service .....	3-11	3-11
Hydraulic system service .....	3-17	3-12
.....	3-19	3-13
.....	3-16	3-11
.....	3-18	3-13
.....	3-15	3-11
.....	3-20	3-13
.....	3-119	3-56
.....	3-120	3-57
.....	3-103	3-49
.....	3-135	3-64
.....	3-90	3-45
.....	3-86	3-40



	Paragraph	Page
Platform -----	3-121	3-57
Pressure regulating valve, engine oil -----	3-73	3-33
Preventive maintenance services (See Maintenance services, preventive)		
Pulley, crankshaft -----	3-87	3-40
Pump drive belt, hydraulic -----	3-112	3-52
Pump, fuel -----	3-54	3-19
Pump, hydraulic -----	3-113	3-52
Pump, water -----	3-78	3-37
Quarterly preventive maintenance service -----	3-7	3-6
Radiator -----	3-75	3-35
Radio Interference Suppression		
Definitions -----	3-47	3-18
Interference suppression components -----	3-49	3-19
Methods to attain proper suppression, general -----	3-48	3-19
Replacement of suppression components -----	3-50	3-19
Testing of suppression components -----	3-51	3-19
Receptacle, trouble light -----	3-109	3-52
Record and report forms -----	1-2	1-1
Regulator valve, engine oil pressure -----	3-73	3-33
Rolls and roll scrapers, description -----	3-123	3-60
Drive roll adjustment -----	3-125	3-60
Guide roll adjustment -----	3-124	3-60
Roll scrapers -----	3-126	3-61
Salt water or high humidity area, operation in -----	2-18	2-10
Scope -----	1-1	1-1
Scrapers, roll -----	3-126	3-61
Seat assembly -----	3-117	3-56
Sending unit, engine oil pressure -----	3-105	3-51
Sending unit, fuel level -----	3-56	3-20
Sending unit, torque converter oil pressure -----	3-104	3-51
Sending unit, torque converter oil temperature -----	3-106	3-51
Sending unit, water temperature -----	3-80	3-38
Service upon receipt of equipment -----	2-1	2-1
Solenoid, starter and -----	3-64	3-26
Spark plugs and cables -----	3-66	3-27
Special tools and equipment -----	3-1	3-1
Sprinkler, pedals and linkage -----	3-95	3-48
Sprinkler system, description -----	3-127	3-62
Sprinkler system, valves, lines, hoses, and fittings -----	3-129	3-62
Sprinkler, water tank -----	3-128	3-62
Starter and solenoid -----	3-64	3-26
Starting the engine -----	2-9	2-6
Stopping the engine -----	2-10	2-6
Steering cylinder -----	3-111	3-52
Steering valve, lever and linkage -----	3-93	3-45
Steering control and pressure regulator valve -----	3-114	2-52
Steering yoke and kingpin adjustment -----	3-137	
Suppression components, interference -----		
Switches, floodlamp -----		

	Paragraph	Page
Lubrication information, general .....	3-3	3-1
Lubrication system, description .....	3-71	3-32
Oil filter, lines and fittings .....	3-72	3-32
Oil pressure regulator valve, engine .....	3-73	3-33
Magneto .....	3-65	3-26
Maintenance services, preventive		
Daily .....	3-6	3-6
General .....	3-5	3-6
Quarterly .....	3-7	3-6
Manifold assembly .....	3-83	3-39
Meter, hour .....	3-102	3-49
Movement to new worksite .....	2-5	2-5
Muffler .....	3-85	3-40
Normal conditions, operation under .....	2-11	2-6
Nut and bolt torque data		
Oil filter .....	3-72	3-32
Oil pressure gage, engine .....	3-96	3-43
Oil pressure gage, converter .....	3-100	3-49
Oil pressure regulator valve, engine .....	3-73	3-33
Oil pressure sending unit, engine .....	3-105	3-51
Oil pressure sending unit, torque converter .....	3-104	3-51
Oil temperature sending unit, torque converter .....	3-106	3-51
Operation:		
Handling on paving jobs .....	2-14	2-9
In dusty or sandy areas .....	2-17	2-10
In extreme cold .....	2-15	2-9
In extreme heat .....	2-16	2-10
In high altitude .....	2-19	2-10
In salt water or high humidity areas .....	2-18	2-10
On Bituminous—concrete and sheet asphalt pavement .....	2-13	2-9
On Bituminous—Macadam pavement .....	2-12	2-8
Under normal conditions .....	2-11	2-6
Operation of equipment		
Starting the engine .....	2-9	2-6
Stopping the engine .....	2-10	2-6
Operator's maintenance		
Ballast rolls service .....	3-21	3-13
Carburetor .....	3-9	3-11
Clutches, forward and reverse, adjustment .....	3-14	3-11
Cooling system service .....	3-12	3-11
Fan belt .....	3-13	3-11
Fuel pump .....	3-10	3-11
Fuel tank service .....	3-11	3-11
Hydraulic system service .....	3-17	3-12
Mats .....	3-19	3-13
Parking brake .....	3-16	3-11
Sprinkler system .....	3-18	3-13
Service brake .....	3-15	3-11
Water tank strainer screen .....	3-20	3-13
Panels, covers and dirt shields .....	3-119	3-56
Panel, instrument .....	3-120	3-57
Panel light, instrument .....	3-103	3-49
Parking brake .....	3-135	3-64
Parking brake, lever and linkage .....	3-90	3-45
Pipe, exhaust .....	3-86	3-40

By Order of the Secretary of the Army:

Official:

KENNETH G. WICKHAM  
Major General, United States Army,  
The Adjutant General.

HAROLD K. JOHNSON,  
General, United States Army,  
Chief of Staff.

Distribution:

*Active Army:*

USASA (2)  
ACSI (1)  
DCSLOG (1)  
CNGB (1)  
TSG (1)  
CofEngrs (3)  
CC-E (1)  
Dir of Trans (1)  
CofSptS (1)  
USAMB (1)  
USA Arty Bd (2)  
USA Armor Bd (2)  
USAIB (2)  
USARADB (2)  
USAAESWBD (2)  
USAAVNTBD (2)  
USCONARC (3)  
OS Maj Comd (5) except  
    USARJ (1)  
USASETAF (2)  
USAMC (1)  
USACDCEC (10)  
USAMECOM (46)  
MDW (1)  
Armies (2)  
Corps (2)  
USAC (1)  
Div (2)  
Engr Bde (1)  
USMA (2)  
Svc Colleges (2)  
Br Svc Sch (2) except

USAES (3)  
Gen Dep (10)  
Engr Dep (10)  
Army Dep (2) except  
    TOAD (3)  
USA Tml Comd (2)  
Army Tml (1)  
Div Engr (2)  
Engr Dist (2)  
Engr Cen (5)  
Engr FLDMS (2)  
Ft Knox FLDMS (10)  
AMS (3)  
MAAG (1)  
JBUSMC (1)  
Army Attaches (1)  
Mil Msn (1)  
USACOMZEUR (2)  
USA Mbl Equip R&D Cen (3)  
USAREUR Engr Proc Cen (2)  
USAREUR Engr Sup Con Agcy (10)  
Fld Comd, DASA (8)  
Units org under fol TOE:  
    5-48 (2)  
    5-114 (2)  
    5-237 (5)  
    5-262 (5)  
    5-267 (1)  
    5-278 (5)  
    5-279 (2)  
    5-500(EA, EB) (2)

NG: None.

USAR: Same as Active Army except allowance is one (1) copy for each unit.

For explanation of abbreviations used, see AR 320-50.

**TM 5-3895-272-12**

	Paragraph	Page
Throttle lever and linkage -----	3-94	3-46
Tool box -----	3-122	3-57
Tools and equipment, basic -----	3-2	3-1
Tools and equipment, special -----	3-1	3-1
Torque converter, oil pressure sending unit -----	3-104	3-51
Torque converter, oil temperature sending unit -----	3-106	3-51
Transmission, description -----	3-130	3-64
Forward and reverse clutch adjustment -----	3-14	3-11
Service brake adjustment -----	3-15	3-11
Transmission breather -----	3-134	3-64
Transmission lever and linkage -----	3-133	3-64
Trouble light -----	2-21	2-11
Trouble light receptacle -----	3-109	3-52
Trouble shooting, general -----	3-22	3-16
Unloading the equipment -----	2-1	2-1
Unpacking the equipment -----	2-2	2-1
Valves -----	3-84	3-40
Valves, pressure regulating -----	3-114	3-53
Valve, steering control -----	3-114	3-53
Water pump -----	3-78	3-37
Water tank -----	3-128	3-62
Water temperature sending unit -----	3-80	3-38
Wiring and wiring harness -----	3-70	3-30
Yoke, steering adjustment -----	3-137	3-65

By Order of the Secretary of the Army:

HAROLD K. JOHNSON,  
General, United States Army,  
Chief of Staff.

Official:

KENNETH G. WICKHAM  
Major General, United States Army,  
The Adjutant General.

Distribution:

*Active Army:*

USASA (2)  
ACSI (1)  
DCSLOG (1)  
CNGB (1)  
TSG (1)  
CofEngrs (3)  
CC-E (1)  
Dir of Trans (1)  
CofSptS (1)  
USAMB (1)  
USA Arty Bd (2)  
USA Armor Bd (2)  
USAIB (2)  
USARADBD (2)  
USAAESWBD (2)  
USAAVNTBD (2)  
USCONARC (3)  
OS Maj Comd (5) except  
    USARJ (1)  
USASETAF (2)  
USAMC (1)  
USACDCEC (10)  
USAMECOM (46)  
MDW (1)  
Armies (2)  
Corps (2)  
USAC (1)  
Div (2)  
Engr Bde (1)  
USMA (2)  
Svc Colleges (2)  
Br Svc Sch (2) except

USAES (3)  
Gen Dep (10)  
Engr Dep (10)  
Army Dep (2) except  
    TOAD (3)  
USA Tml Comd (2)  
Army Tml (1)  
Div Engr (2)  
Engr Dist (2)  
Engr Cen (5)  
Engr FLDMS (2)  
Ft Knox FLDMS (10)  
AMS (3)  
MAAG (1)  
JBUSMC (1)  
Army Attaches (1)  
Mil Msn (1)  
USACOMZEUR (2)  
USA Mbl Equip R&D Cen (3)  
USAREUR Engr Proc Cen (2)  
USAREUR Engr Sup Con Agcy (10)  
Fld Comd, DASA (8)  
Units org under fol TOE:  
    5-48 (2)  
    5-114 (2)  
    5-237 (5)  
    5-262 (5)  
    5-267 (1)  
    5-278 (5)  
    5-279 (2)  
    5-500(EA, EB) (2)

NG: None.

USAR: Same as Active Army except allowance is one (1) copy for each unit.

For explanation of abbreviations used, see AR 320-50.